

ASSEMBLY INSTRUCTIONS

Williams Sonoma Cantilever base

- ① Set STEEL FRAME in final location, including inside the umbrella.
- ② Remove 4 x 1/2" mounting bolts by using 3/4" wrench turning counterclockwise. Place the security stem on the in-ground base mount and reinsert the 4 mounting bolts into the leveling nuts. Screw the mounting bolts into the STEEL FRAME, but DO NOT TIGHTEN the bolts completely.
- ③ Check the security stem with a level in 2 positions with each positioned 90° from each other. To level the security stem, turn the leveling nut clockwise until level. Repeat this step with all 4 leveling nuts until the security stem is leveled to the STEEL FRAME. Tighten all 4 mounting bolts securely with 3/4" wrench.
- ④ Install Concrete Pavers into the STEEL FRAME.
- ⑤ Slide GROUND COVER on to PAVERS plus STEEL FRAME.

