

SAUSALITO KITCHEN ISLAND


Date: 2016-June-26

Important Safety Instructions:


- Please read all instructions carefully before assembling.
- For your safety, assembly by four or more adults is strongly recommended.
- Keep instructions for future use.
- Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.

Pre-assembly:

- Remove all parts and hardware from the box and lay out on a clear carpeted or scratch-free work surface, as this will avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.



Hardware Included:




Date: 2016-June-26 www.williams-sonoma.com

Assembly Instruction Steps:

1. Remove all the drawers of the Base Frame (B) 100%, and set it aside, as seen in the illustration below.

Note: Drawer removal:


Simply press the front release device to remove the drawer.



- 2. Open the Side Door of the Base Frame (B).
- 3. Attach the left and right Side Panel (C&D) to the Base Frame (B).

(Note: Align side panel holes with holes in base frame).


4. Insert 8 sets of: Allen Bolt (3), Spring Washer (4), and Flat Washer (5) from the interior of the base frame and into the pre-installed metal insert on the left and right side panels, as seen in the illustration below.




Date: 2016-June-26 www.williams-sonoma.com Page 3 of 7

- 6. Place the Bottom Panels (E) to the Base Frame (B).
- 7. Use a level gauge to check if the Base Frame (B) is seated flat on the ground. If it is not level and it rocks, adjust the levelers (in or out) until the cabinet sits firmly and level on the floor.

Note: The base must be leveled before assembling the Marble Top (A).




8. Attach the Marble Top (A) to the Base Frame (B) by aligning the holes underneath the Marble Top with the Wood Dowels (6) as seen in the illustration below.




Date: 2016-June-26 www.williams-sonoma.com

Page 4 of 7


9. Attach the Base Frame (B) to the Marble Top (A) using insert 4 sets of: Allen Bolt (2), Spring Washer (4), and Flat Washer (5) from the interior of the left and right side panels and into the pre-installed metal insert on the base frame, (as seen in Diagram A & B)






Date: 2016-June-26

- 10. To assemble the Knobs to the Door, follow these below steps:
 - A. Open the door and remove the Knobs from the inside of the Door front, by unscrewing the Machine Screws found on Door front, "Diagram AA".
 - B. Place the Knobs over the pre-drilled holes on the Door. Insert the original Machine Screws through the holes from the inside of the Door and into the Knobs, "Diagram BB".
 - C. Tighten the Machine Screws using a Philips Head Screwdriver (not included).



- 11. To assemble the Knobs to the Drawers, follow these below steps:
 - A. Remove the Knobs from the inside of the Drawer Boxes, by unscrewing the Machine Screws found on Drawer Front, "Diagram CC".
 - B. Place the Knobs over the pre-drilled holes on the Drawer Front. Insert the original Machine Screws through the holes from the inside of the Drawer Box and into the Knobs, "Diagram DD".
 - C. Tighten the Machine Screws using a Philips Head Screwdriver (not included).




Date: 2016-June-26 www.williams-sonoma.com Page 6 of 7


Place all drawers into the side Drawers of the Kitchen, as seen in the illustration below.

Note: Tool-Less Height adjustement :

Simply rotate the wheel at the front bottom of the drawer to adjust the drawer height



If you wish to reposition the shelf found in the Kitchen, remove the wood screw underneath the shelf and adjust 13. to your desired position.



Care Instructions:

- Always use a chopping board on the Marble Top to prevent any scratching.
- Refrain from dropping heavy objects on the marble top.
- Dust often using a clean, soft, dry, and lint-free cloth.
- Blot spills immediately and wipe with a clean, damp cloth.
- We do not recommend the use of chemical cleansers, harsh abrasives, household cleaners, or furniture polish on our lacquered finish -as they may damage the finish. The marble is not treated and is porous, which can stain particularly with dark liquids.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.

Thank you for your purchase Stores | catalog

Date: 2016-June-26 Page 7 of 7 www.williams-sonoma.com