

The Grand Grill Daddy Platinum™



Instructions: Grand Grill Daddy Platinum- GL13186

The Grill Daddy™ is specifically designed to clean grills quickly, easily and thoroughly with the power of steam. For best results, preheat your grill on high for 10 minutes to burn off as much baked on food residue as possible.

WARNING :Before grilling always check the grill grates for harmful debris and check grill brushes for loose bristles and replace before use.

1. Make sure the on/off water valve is turned cross wise in the off position.
2. Unscrew the water fill cap and fill the Grill Daddy with water, replace the screw cap and tighten until snug. During use, water flow can be regulated by placing index finger over hole in the cap. When turned off, the water will still flow until the water channel is completely evacuated. Grill Daddy is designed to allow the water to flow over the scraper brush to generate steam also.

****DO NOT USE SOAP OR OTHER CLEANING DETERGENTS - USE ONLY WATER.****

-Convenient hanger allows for easy storage.

-The handy V Scraper breaks up the toughest burned on gunk –cleans griddles also.

3. Drain water after each use. Drain for winter storage.

Brushes are easily replaceable. Use: part # GW0405CS

Brush heads are DISHWASHER SAFE. To remove the brush, turn the Grill Daddy over and unscrew the wing nut and slide the brush forward and out. US and international patents and patent pending US# 7,632,033B2,US D562563 S, China Patent # ZL200880108531.5 Reg. US Trademark 3,444,903,4,390,846. China trademark 11442525. Made in China

11/30/2019