

Place cherries in the pitting receiver tray.

The first cherry will slide to the planned housing for pitting.

It is then sufficient to press the push handle that will come down and the cherry kernel will propel the in the receiver tray.

Releasing the push handle the pitted cherry will fall into the container.

You can then continue to pit your cherries after each other.

Cleaning and Maintenance:

You can clean the unit by washing with warm water under the tap. Cleaning can be done with the aid of a damp cloth.

NOTICE DU DENOYAUTEUR
A CERISES
Ref N4044




DO NOT LEAVE THE UNIT IN THE REACH OF CHILDREN. USE THE APPLIANCE ON A FLAT SURFACE.
MUST SET THE DEVICE USING THE VACUUM SEAL BASE.


Mounting:

Remove the pieces from the bag:-

Insert the bottom pusher into place. The threaded end should come out from the top.



Position the spring in the upper part of the push.



Screw the black button on the end of the pusher.
The spring will then be imprisoned.



Insert the red plastic rubber into place. Be careful to insert the rubber side, the cross should be on the left.



Remove the clear bin of cores from its housing, remove the plastic bag and put back in place.