



Desmond Floor Lamp Assembly Instructions

Important Safety Instructions:

- This portable luminaire has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Do not attempt to defeat this safety feature.
- These instructions are provided for your safety. It is important that they are read carefully and completely before assembling fixture.
- This fixture has been rated for up to (1) 100-WATT MAXIMUM TYPE A STANDARD BULB (not included) OR (1) 23W Compact Fluorescent bulb (H) (included). To avoid the risk of fire, do not exceed the recommended wattage.

Warning:

- To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

Parts Enclosed:

- (1) Finial (A)
- (1) Harp (B)
- (1) Harp saddle (C)
- (1) Lamp pole (D)
- (1) Lamp base (E)
- (1) Base weight (F)
- (1) Felt paper (G)
- (1) CFL light bulb (H)

Hardware included:

- (1) Washer (a)
- (1) Nut (b)
- (1) Wrench (c)

Pre-assembly:


- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

To Assemble:

1. Remove all parts carefully from box.
2. Join lamp pole (D), lamp base (E) and base weight (F) together, and slide washer (a) over the threaded pipe which protrudes from bottom of base weight (F).
3. Screw nut (b) onto the threaded pipe to secure lamp base to lamp pole, and tighten with wrench (c) provided.
4. Remove the backing sheet from felt paper (G), affix the felt paper (G) underneath the base weight (F).
5. Insert harp (B) into harp saddle (C).
6. Unscrew the finial (A) from the harp (B) and place the desired shade (not included) over the harp.
7. Attach the finial (A) and tighten to secure the shade.
8. Insert bulb into the socket.
9. Plug lamp into proper electrical outlet and test fixture.

Care Instructions:

- Wipe with soft dry cloth only
- Always avoid the use of harsh chemicals or abrasives as they may damage the finish



thank you for your purchase

Williams Sonoma, Inc. | Customer Service 1.877.812.6235 | www.williams-sonoma.com