

Vertical Planter Dimensions:

33.4 in W x 23.5 in D x 46.25 in H (84.8 cm W x 59.7 cm D x 117.5 cm H)

Customer Service Information

Seville Classics, Inc.


Telephone: (800) 323-5565

Fax: (310) 533-3899

Hours: 8:30 AM – 4:30 PM (PST)

Email: Support@SevilleClassics.com

Online Store: www.SevilleClassics.com



Acacia Wood 3-Tier Vertical Planter

Model #: FRN04729B

Thank you for choosing Seville Classics!

We hope you enjoy your new 3-tier vertical planter.
Please read through these assembly instructions and frequently
asked questions to ensure proper assembly.


The contact information for our live customer support team based in California is on the last page.

Please review the below parts list to ensure you received all the necessary parts.
If you are missing any parts or have trouble with assembly,
please contact our live customer support team at **(800) 323-5565** or
Support@sevilleclassics.com, which can assist you in both English and Spanish.

Parts List




A. Side Frame (2 pcs)




B. Long Base Frames (2 pcs)




C. Short Base Frames (2 pcs)



D. Side Frames (6 pcs)



E. Front Panels (6 pcs)



F. Planter Bases (3 pcs)




G. Hex Nuts (4 pcs)




H. Washers (44 pcs)



I. Wing Nuts (18 pcs)



J. Screws M6 x 50 mm (8 pcs)



K. Phillips screws #4 (24 pcs)



L. Bolt M6 x 50 mm (18 pcs)



M. Bolt M6 x 60 mm (4 pcs)



N. Allen key (1 pc)



WARNING

- Please read the assembly instructions carefully before assembling and using the vertical planter.
- Only use the vertical planter for its intended, non-commercial use (e.g., planting vegetables, flowers and plants).
- **Danger of tipping!** Do not lean against the raised bed. The raised bed can tip over.
- **Do not expose planter to fire or other heat sources.**

Please visit **sevilleclassics.com** to shop our wide range of products.

★ If the position of the planter box tiers need to be re-adjusted, simply loosen the wing nuts, adjust the titled angle and re-tighten the wing nuts to set the positions of each tier.

Planter Volume (each tier): approx. 23 Liters

Total Weight Capacity: 132 lb. (60 kgs.)




Note:


Please be considerate of the environment and recycle the brown box the item was delivered in along with all applicable packaging materials. Thank you.

STEP 5.

Insert each of the three **PLANTER BASES (F)** into each planter box tier.
Your 3-Tier Vertical Planter is now assembled!



TOOLS NEEDED (Tools not included)




Scissor



Knife



Phillips screwdriver




Wrench

Feel free to contact our customer service team if you need help with assembly, have questions, or need any missing parts. Our live customer support team is based in California and available to assist you in both English and Spanish.

Please make sure you have all the parts on this list.
If you are missing parts, contact us for replacements at **(800) 323-5565** or
send an email to **Support@SevilleClassics.com**.


STEP 1.

Use eight **SCREWS (J)** to connect the two **LONG BASE FRAMES (B)** to the two **SHORT BASE FRAMES (C)**.




STEP 2.

Attach two **SIDE FRAMES (A)** to the base frame from the inside using four **BOLTS (M)**, four **HEX NUTS (G)** and eight **WASHERS (H)**. Make sure to place washers on both sides of the frame.



STEP 3.

Use eight **PHILLIPS SCREWS (K)** to connect two **FRONT PANELS (E)** and two **SIDE FRAMES (D)** of each tier of the planter box. Repeat this step for the other two planter box tiers.



STEP 4.

Slide each of the three assembled planter box tiers from above onto the two **SIDE FRAMES (A)**. Secure each planter box tier on both sides of the **SIDE FRAMES (A)** using six **BOLTS (L)**, twelve **WASHERS (H)** and six **WING NUTS (I)**.

Attention! You can set the desired tilted angle for each planter box tier at this step.

