

BRIDGEHAMPTON OUTDOOR DINING TABLE

Important Safety Instructions:


- Please read all instructions carefully before assembling.
- For your safety, assembly by two or more adults is strongly recommended.
- Keep instructions for future use.
- Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.

Pre-assembly:






- Remove all parts and hardware from the box and lay out on a clear carpeted or scratch-free work surface, as this will avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions.
- The use of power tools to aid in assembly is not recommended. Power tools can damage hardware.

Parts Included:


(A)	Top Frame	1x
(B)	Glass Panel	1x
(C)	Stretcher	1x
(D)	Sleeve	1x
(L)	Left Leg	2x
(R)	Right Leg	2x
(K)	Cap	1x



Hardware Included:

(E)	(F)	(G)	(H)	(I)
Pan Head Bolt	Spring Washer	Flat Washer	Countersink Head Bolt	Glass Pad
				
Dia. 6 x16mm 12x	12x	12x	Dia. 6 x16mm 8x	16x




Tools Required (included):





(J) Allen Key 4mm

Assembly Instruction Steps:



1. Carefully lay the Stretcher (C) upside down on a smooth scratch free surface as shown with the screw holes facing up. Attach the leg (L) to the stretcher by using Pan Head Bolt (E) thru Spring Washer (F) and Flat Washer (G). Be sure you identify and attach the leg marked with "L" on the tenon to the stretcher end with same mark as "L". **DO NOT** fully tighten all bolts until the whole table is assembled. Repeat this step for Leg (R).





2. Carefully lay the table Top Frame (A) on a smooth scratch free surface as shown. Insert the above assembled unit to the Top Frame as shown.






3. Fix the leg bracket by using Pan Head Bolt (E), Spring Washer (F) and Flat Washer (G).
Fix the leg post by using Countersink Head Bolt (H). **And Finally tighten up all bolts with Allen Key (J).**



4. Upright the table. Place the Glass Pad (I) along the L-shape edge by 5 pieces at each long side and 3 pieces at each short side. Carefully lay on the Glass Panel (B). If needed, adjust the levelers located at the base of each leg to make the table level. Assembly is complete.




5. Middle hole at glass top for umbrella.




Remove Sleeve (D) from glass top:

- Press the clip under the sleeve



- Pull out the sleeve from glass top



Care Instructions:

- Dust often using a clean, soft, dry and lint-free cloth.
- Blot spills immediately and wipe with a clean, damp, cloth.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.

Thank you for your purchase
Stores | catalog