




## Farmhouse Table with extensible top

### Assembly Instructions



#### Pre-Assembly:

- Please read all instructions carefully and completely before assembly.
- Remove all parts and hardware from box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid discarding small parts or hardware accidentally.
- For your convenience and ease, assembly by two people is strongly recommended.
- Once assembled, periodically check to ensure all bolts are tightened.

#### Parts Included:

- (1) Table top
- (2) Leaves
- (4) Legs with two pre-fixed bolts

#### Hardware Included:

- (8) Nuts size 3/8" inside dia.
- (8) Flat Washers size 3/8" in dia.
- (8) Lock Washers size 3/8" inside dia.
- (1) Open Wrench 2-9/16" length

#### Assembly Instructions:

1. Carefully lay tabletop upside down on a carpeted or scratch-free surface; carefully unpack all legs.
2. With a Phillips screwdriver remove the temporary locks (two wooden blocks) secured underneath the tabletop, as instructed on the attached labels.
3. Align the bolts of one leg into the pre-drilled holes in the corner plaque
4. Slide one flat washer into each bolt
5. Add lock washer into each bolt
6. Add nut and tighten with the open wrench
7. Repeat with the other 3 legs
8. Check to ensure the hardware is properly locked before turning the table.  
Grip the table firmly at each end and turn upright.

#### Leaf Insertion/Removal:



Locked



Unlocked

1. Unlock the swivels located on the underside of the tabletop.

2. Grip table at each end and pull to open. Unpack the leaves, and insert each leaf into position, making sure to match each leaf's pegs with the corresponding holes.
3. Slide table ends closed simultaneously until leaves are securely in place. Turn the swivel to lock.

#### Leaf Storage:

When not in use, leaves should be stored in a flat position, protected each in his own bag. Avoid resting or leaning leave upright. This will prevent misalignment of the leaf apron.

#### Care Instructions:

This item is intended for indoor use only. To clean, use a damp cloth; wipe spills immediately. Avoid the use of cleaners or abrasives as they may damage finish. The use of trivets and coasters on tabletop is recommended to protect the table top.

Thank you for your purchase

Williams-Sonoma Home  
Customer Service 1.888.922.4105  
www.WSHome.com