

## Pourable liquid methylated alcohol

### BEFORE USE:

1. Check the level of liquid methylated alcohol before each use.

### WARNING:

1. **NEVER** fill burner while flame is lit, or hot and not near an open flame. May cause burns and serious injuries and may also result in damage to items that are near to the flame.
2. When in use and to protect your table, **ALWAYS** put the fondue stand on a large heat-proof mat.

### GENERAL USE:

1. Remove the snuffer.
2. Fill the lamp with methylated spirits to the level of the wire lattice. Wipe any excess that drips onto the rim.
3. Place fondue burner into position on the stand. The handle should be parallel to the stand legs so that it can be moved freely for opening and closing the vents.
4. Open the vents by moving the handle to the left. Apply a match to the burner. Adjust the level of the flame by moving the handle to the right, this closes the vents so reducing air to the burner and making the flame smaller. **WARNING:** may cause burns and serious injuries and may also result in damage to items that are near to the flame.
5. To extinguish, close the air holes and replace the snuffer over the burner.

## Pourable gel fondue fuel

### BEFORE USE:

1. Check the level of gel fondue fuel before each use.

### WARNING:

1. **NEVER** fill burner while flame is lit, or hot and not near an open flame. May cause burns and serious injuries and may also result in damage to items that are near to the flame.
2. When in use and to protect your table, **ALWAYS** put the fondue stand on a large heat-proof mat.

### GENERAL USE:

1. Remove the snuffer and vent lid.
2. Remove the insert with wire frame.
3. Pour gel fondue fuel into the base of the fondue burner and fill to slightly below the rim. Wipe any excess that drips onto the rim.
4. Replace vent lid.
5. Place fondue burner into position on the stand. The handle should be parallel to the stand legs so that it can be moved freely for opening and closing the vents.
6. Open the vents by moving the handle to the left. Apply a match to the burner. Adjust the level of the flame by moving the handle to the right, this closes the vents so reducing air to the burner and making the flame smaller. **WARNING:** may cause burns and serious injuries and may also result in damage to items that are near to the flame.
7. To extinguish, close the air holes and replace the snuffer over the burner.

## Pre-Filled Fondue Gel Discs

### WARNING:

1. May cause burns and serious injuries and may also result in damage to items that are near to the flame.
2. When in use and to protect your table, **ALWAYS** put the fondue stand on a large heat-proof mat.

### GENERAL USE:

1. Remove the snuffer and vent lid
2. Remove the insert with wire frame
3. Place pre-filled gel fondue fuel disc into the fondue burner. Remove protective cover from gel fondue fuel disc.
4. Replace vent lid.
5. Place fondue burner into position on the stand. The handle should be parallel to the stand legs so that it can be moved freely for opening and closing the vents.
6. Open the vents by moving the handle to the left. Apply a match to the burner. Adjust the level of the flame by moving the handle to the right, this closes the vents so reducing air to the burner and making the flame smaller. **WARNING: may cause burns and serious injuries and may also result in damage to items that are near to the flame.**
7. To extinguish, close the air holes and replace the snuffer over the burner.

## Pre-Filled Fondue Gel Can

### WARNING:

1. May cause burns and serious injuries and may also result in damage to items that are near to the flame.
2. When in use and to protect your table, **ALWAYS** put the fondue stand on a large heat-proof mat.

### GENERAL USE:

1. Remove the fondue burner from the stand.
2. Securely place pre-filled fondue gel can in the stand.
3. Open gel can.
4. Apply a match to the opening of the gel can. **WARNING: may cause burns and serious injuries and may also result in damage to items that are near to the flame.**
5. To extinguish, cover the flame with a non-flammable metal object (such as lid of gel can, metal spatula, snuffer paddle) that is wider than the flame opening.