

Table lighting Assembly instructions

Important safety instructions:

- These instructions are provided for security reasons. Read them carefully and completely before starting to assemble and install this fixture.
- This portable luminaire has a polarized plug as a safety device (one of the pins is wider than the other) to reduce the risk of electric shock. This plug fits a polarized outlet only in one direction. If it does not fit fully into the socket, reverse it. If it still does not fit, contact a qualified electrician. Never use an extension cord if the plug cannot be fully inserted. Do not modify the plug. Do not try to undo the safety device.
- LED BULBS CAN NOT BE REPLACED.
- This lamp is intended for indoor use.
- Keep these instructions.


CAUTION:

- To avoid the risk of fire, electric shock, or personal injury, always turn off the light and unplugit to cool before changing the light bulb.
- Do not touch the bulb when the light is on. Do not look directly at the lighted bulb.
- Do not get near flammable materials from the lighted bulb.

Pre-assembly:

☐ Remove all parts and materials from the box and all plastic protective packaging.


Tools needed: (notincluded):




Parts included:

- (A) Plastic anchors (2)
- (B) Screws (2)
- (C) Carton (1)

(D) Luminaire base (1)




Procedure:







Determine the desired location of the fixture and temporarily place the cardboard (C) on the wall, mark the 2 places on the cardboard (C) on the wall with a pencil, then remove the cardboard (C) from the marked wall.




Using a drill with a properly sized drill bit (just big enough to make a hole for plastic anchor assemblies (A)), drill a hole in the ceiling at each of the two locations marked for plastic anchors (A).



Insérer les ancrages en plastique (A) dans les deux trous



sont en dehors du mur.



Accrocher le pied du luminaire (D) sur les vis de montage (B) et pousser pur verrouiller la base du lumunaire (D).

Insert the plastic anchors (A) into the two holes in the wall. Insert the mounting screws (B) into the plastic anchors (A) in the wall. Make sure the screw head and 1/8 "wires are out of the wall.

Hang the fixture	e foot (D) on the	mounting screws	(R) and nuch to	lock the lu	minal hase (D)
Halle tile Hattur	פוטטנוטוטוטווווו	IIIOUIIUII2 SCIEWS	TDT and Dustrio	TOCK LITE IT	annan base i b'

FCC COMPLIANCE:

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in commercial premises.

This device generates, uses and can radiate radio frequency energy. As such, if not installed or used in accordance with the instructions, it may disrupt radio communications. However, there is no guarantee against this interference in case the installation does not comply. In the event of interference with radio or television reception, which can be verified by turning the equipment off and on, the user may attempt to resolve the problem in one of the following ways

Reorient or move the antenna.

- Move the equipment away from the receiving station.
- Connect the equipment to a circuit different from that of the receiver.
- Consult the dealer or a qualified radio / TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution:

any changes or modifications made to the device without the express approval of the competent authorities may void the authorization to use it.

COMPLIANCE IC:

This Class B digital apparatus complies with CAN ICES-3 (B) / NMB-3 (B).

Care instructions:

- Wipe with a soft, dry cloth or feather duster.
- Never use strong chemical or abrasive cleaners as they may damage the finish of the fixture.

thank you for your purchase

Stores | catalog | www.williams-sonoma.com United States 1877 812-6235