

WILLIAMS-SONOMA



SIGNATURE TOUCH SERIES
APPAREIL DE CUISINE SIGNATURE

4-SLICE TOASTER USER MANUAL

MANUEL D'UTILISATEUR POUR LE GRILLE-PAIN 4 TRANCHES

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- **READ ALL INSTRUCTIONS.**
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock do not immerse cord, plugs or appliance in water or other liquid.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner or in a heated oven.
- To disconnect, press **STOP**, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
- A fire may occur if toaster is covered or touching flammable material, including curtains, draperies or walls coverings, when in operation.
- Do not attempt to dislodge food when the 4-Slice Motorized Toaster is plugged in.

ADDITIONAL IMPORTANT SAFEGUARD

CAUTION HOT SURFACES: This appliance generates heat and escaping steam during use.

Proper precautions must be taken to prevent the risk of burns, fires or other injury to persons or damage to property.

- A person who has not read and understood all operating, toasting, and safety instructions is not qualified to operate this appliance. All users of this appliance must read and understand this instruction manual before operating or cleaning this appliance.
- If this appliance falls or accidentally becomes immersed in water, unplug it from the wall outlet immediately. **Do not reach into the water!**
- When using this appliance, provide adequate air space above and on all sides for air circulation. Do not operate this appliance while it is touching or near curtains, wall coverings, clothing, dish towels or other flammable materials.
- To reduce the risk of fire, do not leave this appliance unattended during use.
- If this appliance begins to malfunction during use, immediately press **STOP** and unplug the cord. Do not use or attempt to repair a malfunctioning appliance!
- The cord to this appliance should only be plugged directly into a 120V AC 3-prong electrical wall outlet.
- Do not use this appliance in an unstable position.
- Use the 4-Slice Motorized Toaster on a hard, flat surface. Do not place it near a flame or heat or on a soft surface (such as carpet). Avoid placing it where it may tip over during use. Dropping the 4-Slice Motorized Toaster could cause it to malfunction.

NOTE: This 4-Slice Motorized Toaster is equipped with an Anti-Jam feature. If any toast or toaster food gets jammed, the toaster will shut OFF automatically.

WARNING: ELECTRICAL SHOCK HAZARD. Never attempt to dislodge food inside the 4-Slice Motorized Toaster while the toaster is plugged in. Doing so could cause an electrical shock hazard or a risk of fire.

CAUTION: This appliance is hot during operation and retains heat for some time after turning off. Always use oven mitts when handling hot materials and allow metal parts to cool before cleaning. Do not place anything on top of the 4-Slice Motorized Toaster while it is operating or while it is hot.

CAUTION!

- DO NOT TOAST TORN SLICES OF BREAD.
- DO NOT PLACE BUTTERED BREAD OR WRAPPED FOOD INTO THE 4-SLICE MOTORIZED TOASTER.
- DO NOT TOAST SMALL-SIZE BREADS, MINI-BAGUETTES, BREADSTICKS, ETC.

FOR HOUSEHOLD USE ONLY SAVE THESE INSTRUCTIONS

GROUNDING 3-CONDUCTOR PLUG

This appliance is equipped with a grounded-type 3-wire cord (3-prong plug). This plug will only fit into an electrical outlet made for a 3-prong plug. This is a safety feature. If the plug should fail to fit the outlet, contact an electrician to replace the obsolete outlet. Do not attempt to defeat this safety feature.

NOTES ON THE CORD

The provided short power-supply cord should be used to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Do not use an extension cord with this product. Always plug directly into a wall outlet/receptacle.

PLASTICIZER WARNING

CAUTION: The feet on the base of unit contain substances in the plastic, known as plasticizers, that may migrate to the finish of a tabletop or countertop. To prevent this, place nonplastic coasters or placemats between the appliance and the countertop or tabletop. Failure to do so may cause the finish to darken; permanent blemishes or stains can appear.

ELECTRIC POWER


If the electrical circuit is overloaded with other appliances, your appliance may not operate properly. It should be operated on a separate electrical circuit from other appliances.

GETTING TO KNOW YOUR 4-SLICE MOTORIZED TOASTER

PARTS DEFINED

Product may vary slightly from illustration


FIGURE 1



SMART-TOUCH CONTROL PANEL

Intuitively designed, all functions illuminate and emit a beep when they are activated. Once operation has begun for a selected function, the LEFT and/or RIGHT smart-touch control panel displays only the options available within that function. When the 4-Slice Motorized Toaster is plugged in, **POWER** will begin to slowly appear and then pulse slowly on and off. When **POWER** is pressed, a beep can be heard and the main menu (See Figure 2) will appear.

FIGURE 2



STOP. Press **STOP** at any time to interrupt the toasting cycle and to raise the corresponding toasting carriages and turn the 4-Slice Motorized Toaster OFF.

TOAST FUNCTION. Set browning indicator to the desired toast color.

DEFROST FUNCTION. Set browning indicator to the desired toast color. Toasting time is adjusted to give the same degree of browning achieved with unfrozen bread.

BAGEL FUNCTION. Center heating elements are hotter to toast the insides of cut bagels and English muffins perfectly without burning the outsides.

KEEP WARM FUNCTION. Offers 45 seconds of low heat to toasted foods.

Browning Indicator, levels 1 (●) LIGHT to 7 (●●●●●●) DARK.

(+) **PLUS.** Press (+) to increase browning from 1 (●) **LIGHT** to 7 (●●●●●●) **DARK**.

(-) **MINUS.** Press (-) to reduce browning from 7 (●●●●●●) **DARK** to 1 (●) **LIGHT**.

7 BROWNING Lights.

1 (●) **LIGHT.** Press (+) to increase browning.

4 (●●●●) **MEDIUM.** Press (+) to increase or (-) to decrease browning.

7 (●●●●●●) **DARK.** Press (-) to decrease browning.

Dual Crumb Trays LEFT and RIGHT sides (not shown). Crumb trays are located at the back of the 4-Slice Motorized Toaster. (See Figure 9). Press each crumb tray in to release. Pull each crumb tray straight out for cleaning after every use and replace before the next use.

BEFORE USING FOR THE FIRST TIME

- Remove all packaging materials including those that may be inside the toasting slots.
- Wipe the stainless-steel exterior with a damp cloth. Dry thoroughly. Do not use abrasive cleaners.
- Do not place the 4-Slice Motorized Toaster, cord or plug in water.
- Make sure both crumb trays are locked into position at the back of the 4-Slice Motorized Toaster.
- Unwrap the power cord and plug directly into a 120V AC 3-prong electrical outlet. A beep can be heard as the smart-touch control panel plus the LEFT and RIGHT side browning indicator lights 4 (●●●●) **MEDIUM** illuminate.
- It is recommended to run 2 cycles of toast without bread before the first use.

NOTE: Toaster may emit a thin smoke on the initial use. This is normal and not detrimental to the performance of the 4-Slice Motorized Toaster.


DUAL AUTOMATIC CENTERING GUIDES

- Both the LEFT and RIGHT pairs of toasting slots work independently.
- When either the LEFT or RIGHT active controls (**TOAST, DEFROST, BAGEL, KEEP WARM**) are pressed, the corresponding toasting carriages will descend and centering guides will close to hold the bread or toaster food centrally in the toasting slots.

TOASTING

- Since both the LEFT side (Toasting Slots 1 & 2) and RIGHT side (Toasting Slots 3 & 4) work independently, you have the option to toast specialty breads, frozen breads, bagels, waffles, even English muffins at the same time! Be sure to place similar foods in each pair of toasting slots for perfect results.
- Make sure both crumb trays are locked into position at the back of the 4-Slice Motorized Toaster.
- Check to be sure no bread or other objects are inside the toasting slots. Place the 4-Slice Motorized Toaster on a flat, level, heat resistant surface.
- Remove all protective wrappings from food before placing into the toasting slot(s).
IMPORTANT: Avoid toasting torn bread slices or small pieces of toaster food that may get lodged in toasting slot(s).
- Plug the power cord into a 120V AC 3-prong electrical outlet. **POWER** will begin to slowly appear and then pulse slowly on and off. (See Figure 3, **SLEEP Mode**). When **POWER** is pressed, a beep can be heard and the main menu will appear. (See Figure 4, Main Menu)

FIGURE 3



SLEEP MODE


FIGURE 4



MAIN MENU

TOAST

FIGURE 5A



TOAST engaged on LEFT; MAIN MENU awaiting selection on RIGHT.

FIGURE 5B



TOAST engaged on RIGHT; MAIN MENU awaiting selection on LEFT.

FIGURE 5C




TOAST function engaged on both sides.

- NOTE:** Use either toasting slot when toasting only 1 piece of bread or toaster food. Always use slices or foods that fit freely into toasting slots.
- Add 1 to 4 pieces of bread or toaster foods to the LEFT Toasting Slots 1 & 2, and/or to the RIGHT Toasting Slots 3 & 4. If only Slots 1&2 or 3&4 are used, the opposite panel will remain idle. (See Figure 5A and 5B). If toast function is desired for Slots 1&2 and 3&4, LEFT and RIGHT **TOAST** must be pressed. (See Figure 5C)
- Press the LEFT or RIGHT **TOAST** function. From the LEFT or RIGHT side **TOAST** menus, adjust the browning level from 4 (••••) **MEDIUM** by pressing (+) and (-) until the desired browning level 1 to 7 is illuminated.
- The 2 corresponding carriages will descend and toasting will begin.
- While toasting, the selected browning level lights will pulse and count down to a single light as the cycle progresses.
NOTE: The **BROWNING INDICATORS** will act as a progressive timer to show you how much time remains until the toasting cycle will be completed.

- At the end of the toasting cycle, 3 beeps can be heard; corresponding toasting carriages will rise automatically and control panel will return to **SLEEP** mode. Press **POWER** again to activate the main menu if another cycle is desired.
- Remove bread or toaster food from the toasting slot(s). Use care as the top of the 4-Slice Motorized Toaster will still be hot.
CAUTION: Never use a fork or sharp-edged utensil to remove toast, because that may damage the heating element or cause injury.
- The last chosen browning level will be recalled for the next batch.
NOTE: To prevent a fire hazard, never place bread over the opening of the 4-Slice Motorized Toaster; always place bread into the slots.
IMPORTANT! Press the corresponding STOP at any time to interrupt the toasting cycle, raise the corresponding toasting carriages and turn the 4-Slice Motorized Toaster OFF.
NOTE: After 30 seconds of inactivity, the control panel will darken and the 4-Slice Motorized Toaster will advance to **SLEEP** mode.
- Unplug the 4-Slice Motorized Toaster from the wall outlet when not in use and before cleaning.


DEFROST



- NOTE:** Use either toasting slot when toasting only 1 piece of bread or toaster food. Always use slices or foods that fit freely into toasting slots.
- Add 1 to 4 pieces of frozen bread or frozen toaster foods to the LEFT Toasting Slots 1 & 2, and/or to the RIGHT Toasting Slots 3 & 4.
- Press the LEFT or RIGHT **DEFROST** function. From the LEFT or RIGHT side main menu, adjust the browning level from **4 (••••) MEDIUM** by pressing (+) and (-) until the desired browning level 1 to 7 is illuminated.
- The 2 corresponding carriages will descend and toasting will begin.
- While toasting, the chosen browning level lights will pulse and count down to a single light as the cycle progresses.
- At the end of the toasting cycle, 3 beeps can be heard; the corresponding toasting carriages will rise automatically.

- Remove toast or toaster food from the toasting slot(s). Use care as the top of the 4-Slice Motorized Toaster will still be hot.
CAUTION: Never use a fork or sharp-edged utensil to remove bagel or muffin, because that may damage the heating element or cause injury.
NOTE: To prevent a fire hazard, never place bread over the opening of the 4-Slice Motorized Toaster; always place bread into the slots.
IMPORTANT! Press the corresponding STOP at any time to interrupt the toasting cycle, raise the corresponding toasting carriages and turn the 4-Slice Motorized Toaster OFF.
NOTE: After 30 seconds of inactivity, the control panel will darken and the 4-Slice Motorized Toaster will advance to **SLEEP** mode.
- Unplug the 4-Slice Motorized Toaster from wall outlet when not in use and before cleaning.

BAGEL




NOTE: Use the **BAGEL** function for English muffins, too!

- Slice 1 or 2 bagels or English muffins in half; place one half in each toasting slot with the cut sides **facing the center** of the toasting slots.
NOTE: Use either toasting slot when toasting only half a bagel or English muffin. Use slices that fit freely into toasting slots.
- Press the LEFT or RIGHT **BAGEL** function. From the LEFT or RIGHT side main menu, adjust the browning level from **4 (••••) MEDIUM** by pressing (+) and (-) until the desired browning level 1 to 7 is illuminated.
NOTE: When toasting frozen bagels or English muffins, increase 1 to 2 browning levels, depending on the thickness and density of the frozen food.
- The 2 corresponding carriages will descend and toasting will begin.
- While toasting, the chosen browning level lights will pulse and count down to a single light as the cycle progresses.
- At the end of the toasting cycle, 3 beeps can be heard; the corresponding toasting carriages will rise automatically.

- Remove bagel(s) or English muffin(s) from the toasting slot(s). Use care as the top of the 4-Slice Motorized Toaster will still be hot.
CAUTION: Never use a fork or sharp-edged utensil to remove bagel or muffin, because that may damage the heating element or cause injury.
NOTE: To prevent a fire hazard, never place bread over the opening of the 4-Slice Motorized Toaster; always place bread into the slots.
IMPORTANT! Press the corresponding STOP at any time to interrupt the toasting cycle, raise the corresponding toasting carriages and turn the 4-Slice Motorized Toaster OFF.
NOTE: After 30 seconds of inactivity, the control panel will darken and the 4-Slice Motorized Toaster will advance to **SLEEP** mode.
- Unplug the 4-Slice Motorized Toaster from wall outlet when not in use and before cleaning.

KEEP WARM



- Add 1 to 4 pieces of bread or toaster foods to the LEFT Toasting Slots 1 & 2, and/or to the RIGHT Toasting Slots 3 & 4.
- Press the RIGHT or LEFT **KEEP WARM** function. The 2 corresponding carriages will descend and warming will begin.
- The 7 (●●●●●●●) browning indicator lights will pulse and count down to a single light as the **KEEP WARM** cycle progresses.
- At the end of the **KEEP WARM** cycle, 3 beeps can be heard; corresponding toasting carriages will rise automatically.
- Remove bread or toaster food from the toasting slot(s). Use care as the top of the 4-Slice Motorized Toaster will still be hot.
CAUTION: Never use a fork or sharp-edged utensil to remove toast, because that may damage the heating element or cause injury.
NOTE: When warming a single slice, the bread may be placed in any toasting slot.
NOTE: To prevent a fire hazard, never place bread over the opening of the 4-Slice Motorized Toaster; always place bread into the slots.
IMPORTANT! Press the corresponding STOP at any time to interrupt the toasting cycle, raise the corresponding toasting carriages and turn the 4-Slice Motorized Toaster OFF.
NOTE: After 30 seconds of inactivity, control panel will darken and the 4-Slice Motorized Toaster will advance to **SLEEP** mode.
- Unplug the 4-Slice Motorized Toaster from wall outlet when not in use and before cleaning.

REMOVING LODGED FOODS

- NOTE:** This 4-Slice Motorized Toaster is equipped with an Anti-Jam feature. If any toast or toaster food gets jammed, the Toaster will shut OFF automatically.
- If, after toasting, a piece of bread or any other toaster food becomes lodged in either of the toasting slots, unplug the 4-Slice Motorized Toaster and allow it to cool.
 - Turn the 4-Slice Motorized Toaster upside down and shake the food loose.
CAUTION: Never use a fork or sharp-edged utensil to remove toast, because that may damage the heating element or cause injury.

IMPORTANT POINTS

- Remove all protective wrappings from food before placing into the toasting slot(s).
- For best results, clean the crumb tray frequently. See “Care & Cleaning” in this instruction manual.
- Do not block top opening. Do not place any object over the top opening.
- Do not toast buttered bread or buttered pita bread. Melted butter will cause fire.
- When toasting more than one slice of bread, use slices of similar size, thickness and freshness.
- Stale bread, thin bread or sweet bread products, such as teacakes and fruit loaf, brown much more quickly than ordinary bread, so they should be toasted on the lighter settings.
- Never immerse 4-Slice Motorized Toaster, cord or plug in water or other liquid.

MAINTENANCE

This appliance requires little maintenance. It contains no user-serviceable parts. Any servicing requiring disassembly other than cleaning must be performed by a qualified appliance repair technician.

CARE & CLEANING

CAUTION: Do not immerse the 4-Slice Motorized Toaster, cord or plug in water or any other liquid.

CAUTION: Be sure the 4-Slice Motorized Toaster is unplugged before cleaning.


CRUMB TRAY: (See Figure 9). Push to release the LEFT and RIGHT side crumb trays out from the back of the 4-Slice Motorized Toaster. Wipe the crumb tray with a clean, damp cloth. Replace each crumb tray (they are interchangeable), push firmly until a click is heard as each crumb tray is fully inserted and locked into place in the bottom of the 4-Slice Motorized Toaster.

EXTERIOR: Wipe the 4-Slice Motorized Toaster's stainless-steel exterior with a clean, damp cloth. Do not use abrasive cleaners. Do not put cord or plug in water or liquid.

STORING

- Unplug unit, allow to cool. Clean before storing.
- Store 4-Slice Motorized Toaster in its box or in a clean, dry place.
- Never store 4-Slice Motorized Toaster while it is hot or still plugged in.
- Never wrap cord tightly around the appliance, use the cord storage area on the bottom of the 4-Slice Motorized Toaster. (See Figure 9)
- Be sure both LEFT and RIGHT side crumb trays are pushed all the way into the back of the 4-Slice Motorized Toaster. (See Figure 9)

FIGURE 9



- Do not put any stress on the cord where it enters the unit, as this could cause the cord to fray and break.

LIMITED WARRANTY ON WILLIAMS-SONOMA BRANDED ELECTRICS

NOTE: THIS LIMITED WARRANTY CONTAINS AN ARBITRATION CLAUSE AND CLASS ACTION WAIVER PROVISION. IT AFFECTS HOW DISPUTES BETWEEN YOU AND THE COMPANY ARE RESOLVED. BY PURCHASING A WILLIAMS-SONOMA BRANDED ELECTRONIC PRODUCT, YOU AGREE TO BE BOUND BY THIS ARBITRATION PROVISION. PLEASE READ IT CAREFULLY.

Williams-Sonoma hereby warrants that for a period of two years from the date of purchase, this product will be free from mechanical defects in material and workmanship, and for 90 days in respect to non-mechanical parts. At its sole discretion, Williams-Sonoma will either repair or replace the product found to be defective, or issue a refund on the product during the warranty period.

EXCLUSIONS: The Limited Warranty does not cover normal wear of parts, or damage resulting from any of the following: negligent use of the product; use of improper voltage or current; improper routine maintenance; use contrary to the operating instructions; commercial use; or unauthorized service during the warranty period on conditions otherwise covered by the warranty. Also, the Limited Warranty does not cover damages caused by Acts of God such as fire, floods, hurricanes, or tornadoes. Repair or replacement of the product is the only remedy available under this Limited Warranty. Williams-Sonoma shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Other than as provided in this Limited Warranty, the product is being provided “as is.” Any implied warranty of merchantability or fitness for a particular purpose is limited in time to the duration of the Limited Warranty. However, some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, and therefore, the above exclusions or limitations may not apply to you. The warranty gives you specific legal rights, and you may also have other rights that vary by state, province and/or jurisdiction.

HOW TO OBTAIN WARRANTY SERVICE: You must contact Customer Service at our toll-free number: 1-877-504-8004. A Customer Service Representative will attempt to resolve warranty issues over the phone. If the Customer Service Representative is unable to resolve the problem, you will be provided with a case number and asked to return the product to Williams-Sonoma. Products can be returned to a Williams-Sonoma store. Attach a tag to the product that includes: your name, address, daytime contact telephone number, case number, and description of the problem. Also, include a copy of the original sales receipt.

ARBITRATION AGREEMENT & WAIVER OF CERTAIN RIGHTS: Mandatory, Bilateral, and Binding Arbitration: Please read this carefully. It affects your rights. You and the Company agree that any dispute, controversy, or claim arising out of or relating in any way to the Limited Warranty, including any dispute or claim as to the application, enforceability, scope, or interpretation of this agreement to arbitrate, shall be resolved only by final and binding, bilateral arbitration, except that (1) you may assert claims in small claims court if your claims qualify; and (2) this agreement to arbitrate does not include your or the Company's right to seek injunctive or other equitable relief in a court of competent jurisdiction pursuant to the Choice of Law & Jurisdiction provision below, to prevent the actual or threatened infringement, misappropriation, or violation of a party's copyrights, trademarks, trade secrets, patents, or other intellectual property rights. The Federal Arbitration Act, 9 U.S.C. § 1, *et seq.*, and federal arbitration law apply to this agreement and govern all questions as to whether a dispute is subject to arbitration. There is no judge or jury in arbitration, and court review of an arbitration award is limited. An arbitrator, however, can award on an individual basis the same damages and relief as a court (including injunctive and declaratory relief, or statutory damages), and must follow the terms of this Limited Warranty.

The term “Dispute” shall include any dispute, claim, or controversy between you and the Company regarding or relating to any aspect of this Limited Warranty, whether based in contract, statute, regulation, ordinance,

tort (including, but not limited to, fraud, misrepresentation, fraudulent inducement, negligence, or any other intentional tort), or any other legal or equitable theory. The term “Dispute” also includes, but is not limited to, any and all claims between you and the Company in any way related to or concerning this agreement and includes the applicability, enforceability, scope, or interpretation of this agreement to arbitrate. The term “Dispute” is to be given the broadest possible meaning that will be enforced.

DISPUTE NOTICE: Before initiating an arbitration, you and the Company each agree to first provide the other a written notice (“Notice of Dispute”), which shall contain: (a) a written description of the problem and relevant documents and supporting information; and (b) a statement of the specific relief sought. A Notice of Dispute can be (1) mailed to Williams-Sonoma, Inc. Legal Department, 3250 Van Ness Ave, San Francisco, CA 94109, (2) emailed to legal@wsgc.com, or (3) brought to the attention of the Company's Customer Service department at 1-877-504-8004. The Company will provide a Notice of Dispute to you via the mailing address or email address associated with your Account and/or billing information (the “Notice Address”).

You and the Company agree to make attempts to resolve the Dispute prior to commencing an arbitration and not to commence and arbitration proceeding until a 45-day post-notice resolution period expires. If an agreement cannot be reached within forty-five (45) days of receipt of the Notice of Dispute, you or the Company may commence an arbitration proceeding.

ARBITRATION PROCESS AND PROCEDURE: All controversies, claims, counterclaims, or other disputes arising between you and Williams-Sonoma, Inc. relating to this Limited Warranty (“Claim”) shall be submitted for binding arbitration in accordance with the Rules of the American Arbitration Association (“AAA Rules”). The arbitration will be heard and determined by a single arbitrator. The arbitrator's decision in any such arbitration will be final and binding upon the parties and may be enforced in any court of competent jurisdiction. The parties agree that the arbitration will be kept confidential and that the existence of the proceeding and any element of it (including, without limitation, any pleadings, briefs or other documents submitted or exchanged and any testimony or other oral submissions and awards) will not be disclosed beyond the arbitration proceedings, except as may lawfully be required in judicial proceedings relating to the arbitration or by applicable disclosure rules and regulations of securities regulatory authorities or other governmental agencies.

CLASS ACTION WAIVER: NEITHER YOU NOR THE COMPANY SHALL BE ENTITLED TO JOIN OR CONSOLIDATE DISPUTES BY OR AGAINST OTHER INDIVIDUALS OR ENTITIES, OR ARBITRATE ANY DISPUTE IN A REPRESENTATIVE CAPACITY, INCLUDING, WITHOUT LIMITATION, AS A REPRESENTATIVE MEMBER OF CLASS OR IN A PRIVATE ATTORNEY GENERAL CAPACITY, IN CONNECTION WITH ANY DISPUTE. Further, unless both you and the Company expressly agree otherwise, the arbitrator may not consolidate more than one person's claim. If this prohibition of class, representative, or consolidated arbitration is found to be unenforceable, then the entirety of this arbitration provision shall be null and void. If, for any reason, a claim proceeds in court rather than in arbitration, **we each waive our right to a jury trial.**

FEES: In the event you commence arbitration, after Williams-Sonoma receives notice that you have initiated arbitration, the Company will promptly reimburse you for your payment of the filing fee and the Company will pay any case management fees associated with the arbitration and the professional fees for the arbitrator's services.

CHOICE OF LAW & JURISDICTION: This Limited Warranty shall be interpreted, construed, enforced, and governed in all aspects in accordance with the exclusive jurisdiction and laws of California, without regard to conflict of law principles. Any suit, cause of action, or legal proceeding arising under or relating to this Limited Warranty that is not addressed through arbitration or in small claims court as provided above, shall be in the exclusive jurisdiction and venue of the state courts of California, situated in San Francisco County, California or the federal courts situated in the Northern District of California. You and Williams-Sonoma agree to submit to the personal jurisdiction of a state court located in San Francisco County, California or a United States District Court, Northern District of California for any actions which the parties retain the right to seek relief.

PRÉCAUTIONS IMPORTANTES

Lors de l'utilisation d'un appareil électrique, des précautions de sécurité de base doivent être suivies en tout temps, notamment les suivantes :

- **VEUILLEZ LIRE TOUTES LES INSTRUCTIONS.**
- Ne pas toucher les surfaces chaudes. Utiliser les poignées ou les boutons.
- Pour vous protéger des décharges électriques, ne placer en aucun cas le cordon d'alimentation, la fiche ou l'appareil dans l'eau ou dans tout autre liquide.
- Cet appareil n'est pas destiné à être utilisé par des personnes (incluant les enfants) présentant des capacités physiques, sensorielles ou mentales réduites, ou un manque de maturité et de connaissances, à moins qu'elles n'aient été supervisées ou instruites sur l'utilisation de l'appareil par une personne responsable de leur sécurité.
- Une supervision attentive est nécessaire lorsque l'appareil est utilisé par ou près des enfants.
- Débrancher l'appareil lorsqu'il n'est pas en fonction et avant le nettoyage. Laisser refroidir avant d'installer ou de retirer des pièces.
- Ne pas utiliser un appareil si la fiche ou le cordon d'alimentation est endommagé ou si l'appareil fonctionne incorrectement ou a subi quelque dommage que ce soit. Retourner l'appareil au centre de service autorisé le plus près pour un examen, une réparation ou un rajustement.
- L'utilisation d'accessoires non recommandés par le fabricant peut entraîner des blessures.
- Ne pas utiliser à l'extérieur.
- Ne pas laisser le cordon d'alimentation pendre sur le bord d'une table ou d'un comptoir ou toucher une surface chaude.
- Ne pas placer sur ou près d'un élément chaud de cuisinière à gaz ou électrique ou dans un four chaud.
- Pour débrancher l'appareil, appuyer sur le bouton **STOP**, puis retirer la fiche de la prise murale.
- Ne pas utiliser cet appareil pour une autre utilisation que celle à laquelle il est destiné.
- Les aliments surdimensionnés, les emballages en papier d'aluminium ou les ustensiles ne doivent pas être insérés dans le grille-pain puisqu'ils peuvent présenter un risque de feu ou de décharge électrique.
- Un feu peut être provoqué si le grille-pain est couvert ou s'il touche à des matériaux inflammables, incluant les rideaux, les murs ou autres, lorsqu'il est en fonction.
- Ne pas essayer de déloger la nourriture lorsque le grille-pain est branché dans une prise électrique.

PRÉCAUTIONS IMPORTANTES SUPPLÉMENTAIRES

ATTENTION, SURFACE CHAUDE : Cet appareil génère de la chaleur et de la vapeur lorsqu'il est utilisé. Certaines précautions doivent être prises pour éviter les risques de brûlures ou d'autres blessures ainsi que les risques d'incendie et les dommages matériels.

- Les individus n'ayant pas lu et compris toutes les instructions de fonctionnement sécuritaire de cet appareil ne sont pas qualifiés pour le faire fonctionner. Tous les utilisateurs de cet appareil doivent lire et comprendre ce mode d'emploi avant d'utiliser ou de nettoyer cet appareil.
- Si cet appareil est échappé ou accidentellement immergé dans l'eau, le débrancher immédiatement de la prise murale. **Ne pas tenter de le récupérer dans l'eau!**
- Laisser un espace adéquat au-dessus et tout autour de l'appareil pour permettre la circulation de l'air lorsqu'il est utilisé.
- Ne pas utiliser cet appareil lorsqu'il touche ou est situé près de rideaux, de revêtements muraux, de vêtements, de linges à vaisselle ou d'autres matériaux inflammables.
- Pour éviter les risques d'incendie, ne pas laisser le grille-pain sans surveillance lorsqu'il est utilisé.
- Si cet appareil commence à mal fonctionner alors qu'il est en marche, appuyer immédiatement sur **STOP** et débrancher le cordon d'alimentation. Ne pas utiliser ou tenter de réparer un appareil défectueux.

- Le cordon d'alimentation de cet appareil ne peut être branché qu'à une prise électrique AC de 120 volts à 3 broches. Ne pas utiliser cet appareil dans une position instable.
- Utiliser le grille-pain motorisé à 4 fentes sur une surface plate et dure. Ne pas le placer près d'une flamme ou d'une source de chaleur ou sur une surface molle (telle qu'un tapis). Éviter de le placer à un endroit où il risque de basculer pendant l'utilisation. Le grille-pain motorisé à 4 fentes peut mal fonctionner s'il est échappé.

REMARQUE : Ce grille-pain motorisé à 4 fentes est équipé d'une fonction anti-bourrage. Si un pain grillé ou autre aliment reste coincé, le grille-pain s'éteindra automatiquement.

AVERTISSEMENT : RISQUE DE CHOC ÉLECTRIQUE. Ne pas essayer de déloger la nourriture lorsque le grille-pain motorisé à 4 fentes est branché dans une prise électrique. Cela pourrait entraîner un risque de choc électrique ou d'incendie.

ATTENTION : Cet appareil devient chaud lorsqu'utilisé et retient la chaleur un certain temps après avoir été mis hors tension. Toujours utiliser des gants de cuisine lors de la manipulation d'objets chauds et laisser les pièces métalliques refroidir avant de les nettoyer. Ne rien placer sur le grille-pain motorisé à 4 fentes lorsqu'il est chaud ou en marche.

ATTENTION!

- NE PAS FAIRE GRILLER DES TRANCHES DE PAIN DÉCHIRÉES.
- NE PAS PLACER DE PAIN BEURRÉ OU D'ALIMENTS EMBALLÉS DANS LE GRILLE-PAIN MOTORISÉ À 4 FENTES.
- NE PAS FAIRE GRILLER DE PETITS PAINS, DE MINI-BAGUETTES, DE GRESSINS, ETC.

POUR UN USAGE DOMESTIQUE UNIQUEMENT CONSERVER CES INSTRUCTIONS

FICHE À 3 BROCHES DONT UNE DE MISE À LA TERRE

Cet appareil est équipé d'un cordon d'alimentation de type mise à la terre à 3 fils (fiche à 3 broches). Cette fiche ne fonctionne qu'avec les prises électriques conçues pour recevoir les fiches à 3 broches. Il s'agit d'une mesure de sécurité. Si vous ne parvenez pas à insérer la fiche dans la prise, contacter un électricien pour remplacer la prise obsolète. Ne jamais tenter de retirer la broche de mise à la terre.

REMARQUES CONCERNANT LE CORDON D'ALIMENTATION

Le cordon d'alimentation court inclus a pour but de réduire les risques liés à l'emmêlement ou aux trébuchements pouvant résulter de l'utilisation d'un cordon long. Ne pas utiliser de rallonge électrique avec ce produit. Toujours brancher directement dans un réceptacle ou une prise murale.

AVERTISSEMENT CONCERNANT LES PLASTIFIANTS

ATTENTION : Le plastique des pieds de la base de l'unité contient des substances connues sous le nom de plastifiants, qui peuvent déteindre sur les revêtements de comptoir ou de table. Pour éviter que cela se produise, placer un sous-verre ou un napperon en plastique entre l'appareil et le comptoir ou la table. Omettre de le faire pourrait entraîner le noircissement du revêtement et l'apparition d'imperfections ou de taches permanentes.

ALIMENTATION ÉLECTRIQUE


Si le circuit électrique est surchargé avec d'autres appareils, l'appareil peut ne pas fonctionner correctement. Il doit être utilisé sur un circuit électrique séparé des autres appareils.

DÉCOUVREZ VOTRE GRILLE-PAIN MOTORISÉ À 4 FENTES

DÉTAIL DES PIÈCES

Le produit peut différer légèrement de l'illustration.


ILLUSTRATION N° 1



PANNEAU DE COMMANDE À ÉCRAN TACTILE

Toutes les fonctions du panneau conçu de manière intuitive s'illuminent et émettent un signal sonore lorsqu'elles sont activées. Une fois la fonction sélectionnée et l'opération en cours, le panneau de commande à écran tactile à GAUCHE et/ou à DROITE n'affiche que les options disponibles de la fonction choisie. Lorsque le grille-pain motorisé à 4 fentes est branché, le bouton **POWER** commence à apparaître, puis clignote lentement. Lorsque le bouton **POWER** est enfoncé, un signal sonore est émis et le menu principal (Voir l'illustration n° 2) apparaît.

ILLUSTRATION N° 2



STOP (ARRÊTER). Appuyer sur **STOP** à tout moment afin d'interrompre le cycle de grillage, relever les grilles correspondantes et éteindre le grille-pain motorisé à 4 fentes.

FONCTION TOAST (RÔTIR). Régler l'indicateur de coloration selon le degré de grillage désiré.

FONCTION DEFROST (DÉCONGELER). Régler l'indicateur de coloration selon le degré de grillage désiré. Le temps de grillage est ajusté pour obtenir le même degré de coloration que si du pain non congelé était utilisé.

FONCTION BAGEL. Les éléments chauffants du centre sont plus chauds pour faire griller parfaitement l'intérieur des bagels et des muffins anglais coupés sans en brûler la croûte.

FONCTION KEEP WARM (GARDER CHAUD). Offre 45 secondes de faible chaleur aux aliments grillés.

Indicateur de coloration de 1 (●) **PÂLE** à 7 (●●●●●●) **FONCÉ**.

(+) **PLUS.** Appuyer sur (+) pour augmenter la coloration de 1 (●) **PÂLE** à 7 (●●●●●●) **FONCÉ**.

(-) **MOINS.** Appuyer sur (-) pour réduire la coloration de 7 (●●●●●●) **FONCÉ** à 1 (●) **PÂLE**.

7 voyants de **COLORATION**.

1 (●) **PÂLE.** Appuyer sur (+) pour augmenter la coloration.

4 (●●●●) **MOYEN.** Appuyer sur (+) pour augmenter ou sur (-) pour réduire la coloration.

7 (●●●●●●) **FONCÉ.** Appuyer sur (-) pour réduire la coloration.

Plateau ramasse-miettes double, côtés GAUCHE et DROIT non illustrés. Les plateaux ramasse-miettes sont situés à l'arrière du grille-pain motorisé à 4 fentes. (Voir l'illustration n° 9). Appuyer sur les plateaux ramasse-miettes pour les libérer. Retirer chaque plateau ramasse-miettes pour le nettoyer après chaque utilisation et le replacer avant de réutiliser le grille-pain.

AVANT LA PREMIÈRE UTILISATION

- Retirer tous les matériaux d'emballage, y compris ceux pouvant se trouver à l'intérieur des fentes du grille-pain.
- Essuyer l'extérieur en acier inoxydable avec un chiffon humide. Sécher complètement.
Ne pas utiliser de produits de nettoyage abrasifs. Ne pas placer le grille-pain motorisé à 4 fentes, son cordon d'alimentation ou sa fiche dans l'eau.
- S'assurer que les deux plateaux ramasse-miettes sont fixés à l'arrière du grille-pain motorisé à 4 fentes.
- Déballez le cordon d'alimentation et le branchez dans une prise de courant AC à 3 fiches de 120 volts. Un signal sonore sera émis lorsque le panneau de commande intelligent ainsi que les voyants de coloration 4 (●●●●) **MOYEN** à GAUCHE et à DROITE s'illumineront.
- Il est recommandé d'effectuer 2 cycles de grillage sans pain avant la première utilisation.

REMARQUE : Le grille-pain peut dégager une mince fumée lors de sa première utilisation. Cela est normal et ne nuit pas au rendement du grille-pain motorisé à 4 fentes.


GUIDES DE CENTRAGE AUTOMATIQUE DOUBLES

- Les fentes de GAUCHE et de DROITE fonctionnent séparément.
- Lorsqu'un contrôle actif (**TOAST**, **DEFROST**, **BAGEL**, **KEEP WARM**) est enfoncé, tant à GAUCHE qu'à DROITE, les grilles correspondantes s'abaissent et les guides de centrage se ferment pour tenir le pain ou l'aliment en place dans la fente de grillage.

APERÇU DU FONCTIONNEMENT DU GRILLE-PAIN

- Étant donné que le côté GAUCHE (fentes 1 et 2) et le côté DROIT (3 et 4) fonctionnent de façon autonome, vous pouvez faire griller des pains surgelés, des bagels, des gaufres et même des muffins anglais en même temps! S'assurer de placer des aliments similaires dans chaque paire de fentes de grillage pour obtenir de meilleurs résultats.
- S'assurer que les deux plateaux ramasse-miettes sont fixés à l'arrière du grille-pain motorisé à 4 fentes.
- Vérifier qu'il n'y ait pas de pain ou d'autres objets à l'intérieur des fentes de grillage. Placer le grille-pain motorisé à 4 fentes sur une surface plate, horizontale et résistante à la chaleur.
- Retirer tous les emballages des aliments avant de les placer dans la fente de grillage.
IMPORTANT : Éviter de faire griller des tranches de pain déchirées ou des petits morceaux d'aliments pour grille-pain pouvant rester coincés dans les fentes de grillage.
- Brancher le cordon d'alimentation dans une prise de courant à 3 fiches de 120 volts. Le bouton **POWER** commencera à apparaître, puis clignotera lentement. (Voir l'illustration n° 3, Mode **VEILLE**). Lorsque le bouton **POWER** est enfoncé, un signal sonore est émis et le menu principal apparaît. (Voir l'illustration n° 4, Menu principal)

ILLUSTRATION N° 3



MODE VEILLE


ILLUSTRATION N° 4



MENU PRINCIPAL

TOAST (RÔTIR)

ILLUSTRATION N° 5A



La fonction TOAST (RÔTIR) est sélectionnée à GAUCHE; à DROITE, le MENU PRINCIPAL est en attente.

ILLUSTRATION N° 5B



La fonction TOAST (RÔTIR) est sélectionnée à DROITE; à GAUCHE, le MENU PRINCIPAL est en attente.

ILLUSTRATION N° 5C




La fonction TOAST (RÔTIR) est sélectionnée des deux côtés.

- REMARQUE** : Utiliser la fente de grillage de votre choix lorsque vous ne faites griller qu'un morceau de pain ou autre aliment pour grille-pain. Toujours utiliser des tranches ou des aliments qui s'insèrent sans forcer dans les fentes de grillage.
- Placer de une à quatre tranches de pain ou aliments pour grille-pain dans les fentes de grillage de GAUCHE (1 et 2) ou de DROITE (3 et 4). Si seules les fentes 1 et 2 ou 3 et 4 sont utilisées, le panneau de contrôle opposé restera inactif. (Voir les illustrations n° 5A et 5B). Si vous souhaitez activer la fonction pour les fentes 1 et 2 et 3 et 4, vous devez appuyer sur la fonction **TOAST (RÔTIR)** sur les menus de GAUCHE et de DROITE. (Voir l'illustration n° 5C)
- Appuyer sur la fonction **TOAST (RÔTIR)** du côté GAUCHE ou du côté DROIT. Dans le menu **TOAST (RÔTIR)** de GAUCHE ou de DROITE, régler le niveau de coloration à 4 (••••) **MOYEN** en appuyant sur (+) et (-) jusqu'à ce que le niveau de coloration souhaité entre 1 à 7 s'allume.
- Les deux grilles correspondantes s'abaisseront et le cycle de grillage débutera.
- En cours de grillage, les voyants du niveau de coloration sélectionné clignoteront et s'éteindront un à un jusqu'à ce qu'il n'en reste qu'un au terme du cycle.
REMARQUE : Les **INDICATEURS DE COLORATION** agiront comme un décompte vous indiquant combien de temps il reste jusqu'à ce que le cycle de grillage soit terminé.

- Une fois le cycle de grillage terminé, 3 signaux sonores seront émis, les grilles correspondantes se relèveront automatiquement et le panneau de contrôle entrera en mode **VEILLE**. Appuyer à nouveau sur **POWER** pour activer le menu principal si vous souhaitez effectuer un autre cycle.
- Retirer le pain ou l'aliment pour grille-pain de la fente.
Attention : le dessus du grille-pain motorisé à 4 fentes sera encore chaud.
ATTENTION : Ne jamais utiliser de fourchette ou d'outil tranchant pour retirer une rôtie du grille-pain car cela pourrait endommager l'élément de chauffage ou causer des blessures.
- Le niveau de coloration le plus récemment utilisé sera préprogrammé pour le lot suivant.
REMARQUE : Pour éviter les risques d'incendie, ne jamais placer de pain sur l'ouverture du grille-pain motorisé à 4 fentes; toujours placer le pain dans les fentes.
IMPORTANT! Appuyer sur STOP à tout moment afin d'interrompre le cycle de grillage, relever les grilles et éteindre le grille-pain motorisé à 4 fentes.
REMARQUE : Après 30 secondes d'inactivité, le panneau de contrôle s'assombrira et le grille-pain motorisé à 4 fentes entrera en mode **VEILLE**.
- Débrancher le grille-pain motorisé à 4 fentes lorsqu'il n'est pas en fonction et avant le nettoyage.

DEFROST (DÉCONGELER)




DÉCONGELER

- **REMARQUE** : Utiliser la fente de grillage de votre choix lorsque vous ne faites griller qu'un morceau de pain ou autre aliment pour grille-pain. Toujours utiliser des tranches ou des aliments qui s'insèrent sans forcer dans les fentes de grillage.
- Placer de une à quatre tranches de pain ou aliments pour grille-pain congelés dans les fentes de grillage de GAUCHE (1 et 2) ou de DROITE (3 et 4).
- Appuyer sur la fonction **DEFROST (DÉCONGELER)** du côté GAUCHE ou du côté DROIT. Dans le menu principal de GAUCHE ou de DROITE, régler le niveau de coloration à **4 (••••)** **MOYEN** en appuyant sur (+) et (-) jusqu'à ce que le niveau de coloration souhaité entre 1 à 7 s'allume.
- Les deux grilles correspondantes s'abaisseront et le cycle de grillage débutera.
- En cours de grillage, les voyants du niveau de coloration sélectionné clignoteront et s'éteindront un à un jusqu'à ce qu'il n'en reste qu'un au terme du cycle.
- Une fois le cycle de grillage terminé, 3 signaux sonores seront émis et les grilles correspondantes se relèveront automatiquement.
- Retirer la rôtie ou l'aliment pour grille-pain de la fente. Attention : le dessus du grille-pain motorisé à 4 fentes sera encore chaud.
ATTENTION : Ne jamais utiliser de fourchette ou d'outil tranchant pour retirer un bagel ou un muffin anglais du grille-pain car cela pourrait endommager l'élément de chauffage ou causer des blessures.
REMARQUE : Pour éviter les risques d'incendie, ne jamais placer de pain sur l'ouverture du grille-pain motorisé à 4 fentes; toujours placer le pain dans les fentes.
IMPORTANT! Appuyer sur STOP à tout moment afin d'interrompre le cycle de grillage, relever les grilles et éteindre le grille-pain motorisé à 4 fentes.
REMARQUE : Après 30 secondes d'inactivité, le panneau de contrôle s'assombrira et le grille-pain motorisé à 4 fentes entrera en mode **VEILLE**.
- Débrancher le grille-pain motorisé à 4 fentes lorsqu'il n'est pas en fonction et avant le nettoyage.

BAGEL

ILLUSTRATION N° 7



BAGEL

REMARQUE : Vous pouvez utiliser la fonction **BAGEL** pour les muffins anglais aussi!

- Trancher un ou deux bagels ou muffins anglais en deux moitiés et placer une moitié dans chaque fente de grillage, le côté coupé **vers le centre** des fentes de grillage.

REMARQUE : Utiliser la fente de grillage de votre choix lorsque vous ne faites griller qu'une moitié de bagel ou de muffin anglais. Toujours utiliser des tranches qui s'insèrent sans forcer dans les fentes de grillage.

- Appuyer sur la fonction **BAGEL** du côté GAUCHE ou du côté DROIT. Dans le menu principal de GAUCHE ou de DROITE, régler le niveau de coloration à **4 (••••) MOYEN** en appuyant sur (+) et (-) jusqu'à ce que le niveau de coloration souhaité entre 1 à 7 s'allume.

REMARQUE : Si vous faites griller un bagel ou un muffin anglais congelé, augmenter le niveau de coloration de 1 ou 2 en fonction de l'épaisseur et de la densité de l'aliment.

- Les deux grilles correspondantes s'abaisseront et le cycle de grillage débutera.
- En cours de grillage, les voyants du niveau de coloration sélectionné clignoteront et s'éteindront un à un jusqu'à ce qu'il n'en reste qu'un au terme du cycle.
- Une fois le cycle de grillage terminé, 3 signaux sonores seront émis et les grilles correspondantes se relèveront automatiquement.
- Retirer le ou les bagels ou muffins anglais de la fente de grillage. Attention : le dessus du grille-pain motorisé à 4 fentes sera encore chaud.
ATTENTION : Ne jamais utiliser de fourchette ou d'outil tranchant pour retirer un bagel ou un muffin anglais du grille-pain car cela pourrait endommager l'élément de chauffage ou causer des blessures.

REMARQUE : Pour éviter les risques d'incendie, ne jamais placer de pain sur l'ouverture du grille-pain motorisé à 4 fentes; toujours placer le pain dans les fentes.

IMPORTANT! Appuyer sur STOP à tout moment afin d'interrompre le cycle de grillage, relever les grilles et éteindre le grille-pain motorisé à 4 fentes.

REMARQUE : Après 30 secondes d'inactivité, le panneau de contrôle s'assombriera et le grille-pain motorisé à 4 fentes entrera en mode **VEILLE**.

- Débrancher le grille-pain motorisé à 4 fentes lorsqu'il n'est pas en fonction et avant le nettoyage.

KEEP WARM (GARDER CHAUD)

ILLUSTRATION N° 8



GARDER CHAUD

- Placer de une à quatre tranches de pain ou aliments pour grille-pain dans les fentes de grillage de GAUCHE (1 et 2) ou de DROITE (3 et 4).
- Appuyer sur la fonction **KEEP WARM (GARDER CHAUD)** du côté gauche ou du côté droit. Les deux grilles correspondantes s'abaisseront et le cycle de réchaud débutera.
- Les voyants du niveau de coloration **7 (••••••) FONCÉ** clignoteront et s'éteindront un à un jusqu'à ce qu'il n'en reste qu'un au terme du cycle **KEEP WARM (GARDER CHAUD)**.
- Une fois le cycle **KEEP WARM (GARDER CHAUD)** terminé, 3 signaux sonores seront émis et les grilles correspondantes se relèveront automatiquement.
- Retirer le pain ou l'aliment pour grille-pain de la fente.
Attention : le dessus du grille-pain motorisé à 4 fentes sera encore chaud.
ATTENTION : Ne jamais utiliser de fourchette ou d'outil tranchant pour retirer une rôtie du grille-pain car cela pourrait endommager l'élément de chauffage ou causer des blessures.
REMARQUE : Utiliser la fente de grillage de votre choix lorsque vous ne faites réchauffer qu'une seule tranche.
REMARQUE : Pour éviter les risques d'incendie, ne jamais placer de pain sur l'ouverture du grille-pain motorisé à 4 fentes; toujours placer le pain dans les fentes.
IMPORTANT! Appuyer sur STOP à tout moment afin d'interrompre le cycle de grillage, relever les grilles et éteindre le grille-pain motorisé à 4 fentes.
REMARQUE : Après 30 secondes d'inactivité, le panneau de contrôle s'assombriera et le grille-pain motorisé à 4 fentes entrera en mode **VEILLE**.
- Débrancher le grille-pain motorisé à 4 fentes lorsqu'il n'est pas en fonction et avant le nettoyage.

DÉLOGER LES ALIMENTS COINCÉS

REMARQUE : Ce grille-pain motorisé à 4 fentes est équipé d'une fonction anti-bourrage. Si un pain grillé ou autre aliment reste coincé, le grille-pain s'éteindra automatiquement.

- Si, après le cycle de grillage, un morceau de pain ou d'aliment pour grille-pain reste coincé dans l'une des fentes de grillage, débrancher le grille-pain motorisé à 4 fentes et le laisser refroidir.
- Tourner le grille-pain motorisé à 4 fentes à l'envers et le secouer pour déloger l'aliment.
ATTENTION : Ne jamais utiliser de fourchette ou d'outil tranchant pour retirer une rôtie du grille-pain car cela pourrait endommager l'élément de chauffage ou causer des blessures.

INFORMATIONS IMPORTANTES

- Retirer tous les emballages des aliments avant de les placer dans la fente de grillage.
- Pour de meilleurs résultats, nettoyer le plateau ramasse-miettes fréquemment. Consulter la section « Entretien et nettoyage » de ce manuel d'instructions.
- Ne pas bloquer l'ouverture supérieure. Ne pas placer aucun objet sur l'ouverture supérieure.
- Ne pas faire griller de pain beurré ou de pain pita beurré. Le beurre fondu peut provoquer un incendie.
- Lorsque vous faites griller plus d'une tranche de pain, utiliser des tranches de taille, d'épaisseur et de fraîcheur similaires.
- Le pain rassis, le pain mince et les produits de boulangerie sucrés tels que les galettes et les pains aux fruits dorent beaucoup plus rapidement que le pain ordinaire; il convient donc d'utiliser les réglages de coloration moins puissants.
- Ne jamais immerger le grille-pain motorisé à 4 fentes, son cordon d'alimentation ou sa fiche dans l'eau ou dans tout autre liquide.

RÉPARATIONS

Cet appareil nécessite peu d'entretien. Il ne contient aucune pièce réparable par l'utilisateur. Toute réparation nécessitant un démontage autre que pour le nettoyage doit être effectuée par un technicien de réparation d'appareils qualifié.

ENTRETIEN ET NETTOYAGE

ATTENTION : Ne jamais immerger le grille-pain motorisé à 4 fentes, son cordon d'alimentation ou sa fiche dans l'eau ou dans tout autre liquide.


ATTENTION : Toujours s'assurer que le grille-pain motorisé à 4 fentes est débranché avant de le nettoyer.

PLATEAU RAMASSE-MIETTES : (Voir l'illustration n° 9). Appuyer pour retirer les plateaux ramasse-miettes de GAUCHE et de DROITE de l'arrière du grille-pain motorisé à 4 fentes. Essuyer le plateau à l'aide d'un chiffon propre et humide. Remplacer chaque plateau ramasse-miettes (ils sont interchangeables) et appuyer fermement jusqu'à ce qu'un déclic se fasse entendre pour vous assurer que le plateau ramasse-miettes est complètement inséré et fixé en place à l'arrière du grille-pain motorisé à 4 fentes.

EXTÉRIEUR : Essuyer l'extérieur du grille-pain motorisé à 4 fentes en acier inoxydable avec un chiffon propre et humide. Ne pas utiliser de produits de nettoyage abrasifs. Ne pas placer le cordon d'alimentation ou la fiche dans l'eau ou dans tout autre liquide.

RANGEMENT

- Débrancher l'appareil et laisser refroidir. Nettoyer l'appareil avant de le ranger.
- Ranger le grille-pain motorisé à 4 fentes dans sa boîte ou dans un endroit propre et sec. Ne jamais ranger le grille-pain motorisé à 4 fentes pendant qu'il est chaud ou branché.
- Ne jamais enrouler le cordon d'alimentation autour de l'appareil; utiliser l'espace de rangement situé à la base du grille-pain motorisé à 4 fentes. (Voir l'illustration n° 9.)
- S'assurer que les plateaux ramasse-miettes de GAUCHE et de DROITE sont fixés à l'arrière du grille-pain motorisé à 4 fentes. (Voir l'illustration n° 9.)



- Ne jamais étirer le cordon d'alimentation là où il s'insère dans la base de l'appareil, car le cordon pourrait s'effilochoir et se briser.

Developed exclusively for / Conçu en exclusivité pour
WILLIAMS-SONOMA® 2016.

© 2016 Williams-Sonoma, Inc. San Francisco, Ca 94109 USA. / É.-U.
2 Grosvenor Street, Suite 201, Level 2, Bondi Junction, NSW 2022, AUS.

Williams Sonoma: 1-877-504-8004
Made in China / Fabriqué en Chine