



*recipes
inside!*

DPPB120

PORTABLE **USB BLENDER**

Instruction Manual | Recipe Guide







PORTABLE **USB BLENDER**

Important Safeguards.....	4-9
Parts & Features	10
Using Your Portable USB Blender	12-15
Tips & Tricks	16-17
Layering Guide.....	18
Cleaning & Maintenance	19
Recipes	21-35
FCC Compliance Statement.....	36
Industry Canada Statement	37
Customer Support	38
Warranty.....	39

 *the dash team!*

IMPORTANT SAFEGUARDS

IMPORTANT SAFEGUARDS: PLEASE READ AND SAVE THIS INSTRUCTION AND CARE MANUAL.

When using electrical appliances, basic safety precautions should be followed, including:

- Read all instructions carefully.
- Remove all packaging and labels from appliance prior to use.
- To protect against risk of electrical shock, do not put cord, plugs, or appliance in or near water or other liquids.
- For any maintenance other than cleaning, please contact StoreBound directly at 1-800-898-6970 from 9AM – 9PM EST Monday – Friday, or by email at support@bydash.com.
- Keep appliance away from children when in use.
- Unplug the appliance from the charger during assembly, during disassembly, and before cleaning. Do not use appliance while plugged into the charger.
- Avoid contact with moving parts.
- Do not operate this appliance with a damaged charging cable, after the appliance malfunctions, or is damaged in any manner.
- Only use attachments that are recommended or sold by the appliance manufacturer.
- Do not leave this appliance unattended while it is operating.
- Do not let the charging cable hang over the edge of tables, counters, or touch hot surfaces.
- Always make sure that the Bottle is locked securely in place before engaging the motor. Do not remove the Bottle before the blender is finished operating.
- Make sure that the motor stops completely before disassembling.
- Do not place your fingers or other foreign objects into the appliance

IMPORTANT SAFEGUARDS

while it is operating. If food becomes lodged in the blades, turn off before trying to remove the ingredients.

- Do not use the appliance if any of the parts are damaged.
- Do not use without the Lid in place.
- Keep hands and utensils away from moving blades while appliance is engaged to reduce the risk of severe injury or damage to the Blender.
- The blades in the Blender are sharp. Handle carefully. Do not touch the blades in the base of the Bottle with bare hands.
- Do not place the appliance on or near a hot gas plate, hot electric burner, or in a heated oven.
- When cleaning, do not submerge the Blending Base (with electrical parts) in any liquid; instead use a soft, wet cloth to wipe down. The Base is NOT dishwasher safe.
- Do not operate the Blender when the Bottle is empty, as this may damage the blender.
- Do not put your Blender in a microwave oven or freezer.
- Do not put anything carbonated in your Blender, as this may cause pressure to build up that could result in a mess, damage to the blender or possible injury.
- Do not let food sit in your Blender to long periods of time, as this may lead to fermentation which can build pressure in the Bottle to the point of damage or possible injury.
- Do not use hot liquids over 120°F/49°C, as this can cause damage to the jar and base.
- Make sure the Lid is closed tightly during blending to prevent liquid from splashing out.
- Keep hands and utensils out of the Bottle while the motor is running to prevent injuries or damages.
- Keep the blending time below 2 minutes to prevent the motor from overloading or overheating. If the motor stops abruptly, allow the motor temperature to decrease before continuing to blend.
- Always place soft or liquid ingredients in the Blender before adding hard ingredients or ice cubes.

IMPORTANT SAFEGUARDS

- Wait until the blades come to a complete stop before removing the Bottle.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience of knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- This appliance is not a toy. Do not let children use this appliance. Close supervision is necessary when any kitchen appliance is used by or near children.
- StoreBound shall not accept liability for damages caused by improper use of the appliance.

IMPORTANT SAFEGUARDS: PLEASE READ AND SAVE THIS INSTRUCTION AND CARE MANUAL.

GARANTIES IMPORTANTES: VEUILLEZ LIRE ET CONSERVER CE MODE D'EMPLOI ET D'ENTRETIEN

L'utilisation d'appareils électriques nécessite de prendre des mesures de sécurité de base, y compris:

- Lisez attentivement les instructions.
- Retirez tous les emballages et étiquettes de l'appareil avant de l'utiliser.
- Pour éviter tout risque de choc électrique, n'immergez pas le cordon, les fiches ou l'appareil dans de l'eau ou tout autre liquide.
- Pour tout travail d'entretien autre que le nettoyage, veuillez contacter StoreBound directement au 1-1-800-898-6970, de 9 h à 21 h HNE, du lundi au vendredi, ou par courriel à l'adresse support@bydash.com.
 - Gardez l'appareil hors de portée des enfants lorsqu'il est utilisé.
 - Débranchez l'appareil du chargeur pendant le montage,
- pendant le démontage et avant le nettoyage. N'utilisez pas l'appareil lorsqu'il est branché au chargeur
- Évitez tout contact avec les pièces en mouvement.
- N'utilisez pas cet appareil avec un câble de charge endommagé, après un dysfonctionnement de l'appareil, ou s'il est endommagé de quelque manière que ce soit.
- N'utilisez que les accessoires recommandés ou vendus par le fabricant de l'appareil.
- Ne laissez PAS l'appareil sans surveillance lorsqu'il est en marche.
- Ne laissez pas le cordon pendre de la table ou d'un comptoir, ou toucher des surfaces chaudes.

GARANTIES IMPORTANTES

- Assurez-vous toujours que la Bouteille est bien verrouillée en place avant d'engager le moteur. Ne retirez pas la Bouteille avant la fin du fonctionnement du mixeur.
- Assurez-vous que le moteur s'arrête complètement avant de le démonter.
- Ne mettez pas vos doigts ou d'autres objets étrangers dans l'appareil pendant qu'il fonctionne. Si des aliments se logent dans les lames, éteignez l'appareil avant d'essayer de retirer les ingrédients.
- N'utilisez pas l'appareil si l'une de ses pièces est endommagée.
- Ne pas utiliser sans le Couvercle en place.
 - Gardez les mains et les ustensiles à l'écart des lames en mouvement lorsque l'appareil est en marche afin de réduire le risque de blessures graves ou de dommages au mélangeur.
 - Les lames du Mélangeur sont tranchantes. Manipulez-les avec précaution. Ne touchez pas les lames situées à la base de la Bouteille à mains nues.
- Ne placez pas l'appareil sur ou près d'une plaque de gaz chaude, d'un brûleur électrique chaud ou dans un four chauffé.
- Lors du nettoyage, n'immergez pas le socle de mixage (avec les pièces électriques) dans un liquide ; utilisez plutôt un chiffon doux et humide pour l'essuyer. La Base n'est PAS lavable au lave-vaisselle.
- Ne faites pas fonctionner le Mélangeur lorsque la Bouteille est vide, car cela pourrait endommager le blender.
- Ne mettez pas votre Mélangeur dans un four à micro-ondes ou un congélateur.
- Ne mettez rien de gazeux dans votre mélangeur, car cela pourrait provoquer une pression qui pourrait entraîner un dégât, endommager le mélangeur ou éventuellement blesser quelqu'un.
- Ne laissez pas les aliments reposer dans votre Mélangeur pendant de longues périodes, car cela peut entraîner une fermentation qui peut faire monter la pression dans la Bouteille au point de l'endommager ou de blesser.

GARANTIES IMPORTANTES

- N'utilisez pas de liquides chauds à plus de 120°F/49°C, car cela pourrait endommager le pot et la base.
- Veillez à ce que le Couvercle soit bien fermé pendant le mixage pour éviter toute projection de liquide.
- Gardez les mains et les ustensiles hors de la Bouteille lorsque le moteur est en marche pour éviter les blessures ou les dommages.
- Maintenez la durée du mélange en dessous de 2 minutes pour éviter que le moteur ne soit surchargé ou ne surchauffe. Si le moteur s'arrête brusquement, laissez la température du moteur diminuer avant de poursuivre le mélange.
- Placez toujours les ingrédients mous ou liquides dans le Mélangeur avant d'ajouter les ingrédients durs ou les glaçons.
- Attendez que les lames s'arrêtent complètement avant de retirer la Bouteille.
- Cet appareil peut être utilisé par des personnes dont les capacités physiques, sensorielles ou mentales sont réduites ou qui manquent d'expérience ou de connaissances, si elles ont reçu une supervision ou des instructions concernant l'utilisation de l'appareil en toute sécurité et si elles comprennent les risques encourus.
- Cet appareil n'est pas un jouet. Ne laissez pas d'enfants utiliser cet appareil. Une étroite surveillance est nécessaire lorsqu'un appareil est utilisé par ou à proximité d'enfants.
- StoreBound n'accepte pas la responsabilité des dommages causés par une utilisation inappropriée de l'appareil.

GARANTIES IMPORTANTES:
VEUILLEZ LIRE ET CONSERVER CE
MODE D'EMPLOI ET D'ENTRETIEN

PARTS & FEATURES





USING YOUR PORTABLE USB BLENDER



- 1** To charge your Portable USB Blender, plug the USB-C side of your Charging Cable into the Blending Base **(photo A)** and the USB-A side of the Cable into any compatible power adapter.
- 2** Remove the Drinking Lid from the top of the Bottle. Make sure the Bottom Cap is properly attached to the bottom of the Bottle **(photo B)**.

USING YOUR PORTABLE USB BLENDER



- 3** Fill the Bottle with what you'd like to blend (**photo C**). For best performance, see our Layering Guide on Page 18.
- 4** Unscrew and remove the Blade Cover from the Blending Base (**photo D**).

USING YOUR PORTABLE USB BLENDER



- 5 Screw the Base to the top of the Bottle, making sure the small arrow on the Bottle is aligned with the Power Button (**photo E**). Once the Bottle and Base are properly aligned, the Indicator Light will blink once: this means you're ready to blend!
- 6 Flip your Blender over and press the Power Button to start a 40 second blending cycle (**photo F**). Press the Power Button again to stop blending earlier than that.

Chef Tip!



To help blend your ingredients, we recommend gently shaking the blender while it is active.

USING YOUR PORTABLE USB BLENDER



- 7 Once blending has stopped, flip your Blender over and unscrew the Base from the Bottle (photo G).
- 8 Reattach the Drinking Lid to the Bottle and enjoy (photo H)!
- 9 After cleaning your Blending Base, be sure to reattach the Blade Cover to avoid injury and for easy transportation and storage.

TIPS & TRICKS



BLENDING

- Remove fruit peels, pits and seeds before blending. Allow frozen fruit to thaw for at least 15 minutes before blending.
Tip: try prepping your smoothie with frozen fruit the night before and let it thaw in the fridge overnight.
- For best performance, do not blend anything bigger than ½ - 1" sized pieces.
- For best performance, when blending fresh or frozen fruit, mix 1:1 with water or milk.
- Do not blend meat, hard, sticky or dry foods.
- When blending ice, be sure to blend 1:1 with water. Use the smallest sized ice possible.



CHARGING

To extend the life of your Portable USB Blender, we recommend:

- Using the included USB-C Charging Cable to charge it. If lost or misplaced, a non-fast charging USB-C charging cable will work fine. DO NOT use a fast charging USB-C charging cable to charge the Portable USB Blender.
- Charging your Blender once every 2-3 months to keep the rechargeable battery fresh.
- Do **NOT** use the Blender while it is plugged in and/or charging.




INDICATOR LIGHT

The Indicator Light can blink and show a variety of colors, depending on the situation:

- Blink once when the Bottle and Blending Base are aligned.
- Blinks 2-3 times when the base and jar aren't aligned: the blender will not turn on.
- Lights up when blending.
- Red light flashes 8 times: battery is dead.
- White light slowly flashes while it is charging.
- Fully charged: white light will stay on until the charger is removed.
- Blender shuts off and red light flashes 4 times: food is stuck/ overload protection.

LAYERING GUIDE

Once your Bottle is packed, attach the Blending Base, flip and blend!



CLEANING & MAINTENANCE

The Bottle, Drinking Lid, Bottom Cap, and Blade Cover are all top-rack dishwasher safe. The Blending Base is NOT dishwasher safe. Wipe down the Blending Base with a wet cloth to clean.

For a quick and easy way to clean the blades, add warm water (about $\frac{2}{3}$ of the bottle) and a drop of dish soap to your assembled blender and run a blending cycle. When finished, pour out soapy water and rinse.

NEVER touch the blades. Clean using the above method or a nylon cleaning brush.



RECIPE GUIDE



Follow us!

@bydash | recipes, videos, & inspiration

@unprocessyourfood | veg & vegan-friendly meals



BREAKFAST ENERGY SMOOTHIE

Ingredients:

- ¼ cup frozen blueberries
- ½ banana
- ¼ cup oats
- ½ tsp vanilla
- 1 cup milk of choice

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.



Chef Tip!

Add a scoop of your favorite protein powder for an extra kick!



CARROT CAKE SMOOTHIE

Ingredients:

½ frozen banana
1 small carrot chopped or shredded
1 pitted date, cut into pieces
¼ vanilla
1 cup milk of choice
dash of cinnamon
dash of ginger
dash of nutmeg

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.



STRAWBERRY SMOOTHIE BOWL TO GO

Ingredients:

¾ cup frozen sliced strawberries
¼ yogurt
1 tbsp maple syrup,
¾ cup milk of choice
1 tbsp chia seeds



Add a scoop of your favorite protein powder for an extra kick!

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.
4. Serve and top your bowl how you like it! We recommend granola, nuts, seeds, dried fruit, honey, fresh fruit, or coconut flakes.



GREEN DREAM MACHINE

Ingredients:

- ¼ cup baby kale
- ½ frozen banana
- ¼ avocado
- 1 tbsp maple syrup
- 1 tbsp chia seeds
- 1 cup milk of choice

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.



MANGO TURMERIC SMOOTHIE

Ingredients:

½ frozen banana

½ cup frozen mango

1 cup coconut water

1 inch turmeric peeled and chopped or ¼ tsp powdered turmeric
fresh black pepper

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.





CHERRY ALMOND CHIA PROTEIN SMOOTHIE

Ingredients:

½ cup frozen cherries
1 scoop vanilla protein powder
1 tsp vanilla
¼ tsp almond
1 tsp chia seeds
1 cup milk of choice

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.



VEGAN MANGO-COCONUT GREEN SMOOTHIE

Ingredients:

- ½ cup spinach
- ½ cup frozen mango
- ½ frozen banana
- ¾ cup orange juice
- ½ cup coconut milk
- 1 tbsp maple syrup

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.





PESTO SAUCE

Ingredients:

½ cup pine nuts,
½ cup oil
2 cloves garlic
¼ cup fresh grated Parmesan
½ tsp salt
½ cup lemon juice
1 cup fresh basil
fresh black pepper to taste

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency. If the pesto sauce is too thick and won't blend, add more oil or lemon juice to thin it out until it blends smoothly.



PB&J SMOOTHIE

Ingredients:

¼ cup frozen raspberries
1 tbsp creamy peanut butter
1 cup milk of choice
pinch of salt

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.



Add a scoop of your favorite protein powder for an extra kick!



COFFEE PROTEIN SHAKE

Ingredients:

- 1 cup milk of choice
- 1 scoop protein powder
- 2 tsp espresso powder
- ½ tsp vanilla

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.





ORANGE CREAMSICLE SMOOTHIE

Ingredients:

½ frozen banana
2 orange sections, peeled
½ cup yogurt
½ cup orange juice
2 tsp vanilla

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.



OAT MILK LATTE

Ingredients:

- ½ cup cold coffee
- ½ cup water
- 2 tbsp rolled oats
- 1 tbsp maple syrup

Directions:

1. Place all ingredients in your Blending Bottle in the order listed in the Ingredients. Screw the Blending Base into the top of the Bottle and flip it.
2. Turn on the blender and tilt it back and forth one time to distribute the ingredients.
3. Blend to desired consistency.

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:


- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CUSTOMER SUPPORT

**FEEL GOOD
GUARANTEE™**

Dash values quality and workmanship and stands behind this product with our Feel Good Guarantee™. To learn more about our commitment to quality, visit bydash.com/feelgood.

Our customer support teams in the US and Canada are at your service Monday - Friday during the times below.
Contact us at **1 (800) 898-6970** or support@bydash.com



Hey **Hawaii!** You can reach our customer service team from **3AM to 3PM**.
And also, **Alaska**, feel free to reach out from **5AM to 5PM**.

STOREBOUND, LLC - 1 YEAR LIMITED WARRANTY

Your StoreBound product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of the original purchase when utilized for normal and intended household use. Should any defect covered by the terms of the limited warranty be discovered within one (1) year, StoreBound, LLC will repair or replace the defective part. To process a warranty claim, contact Customer Support at 1-800-898-6970 for further assistance and instruction. A Customer Support agent will assist you by troubleshooting minor problems. If troubleshooting fails to fix the problem, a return authorization will be issued. Proof of purchase indicating the date and place of purchase is required and should accompany the return. You must also include your full name, shipping address, and telephone number. We are unable to ship returns to a PO box. StoreBound will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information. Freight costs must be prepaid by the purchaser.

Send all inquiries to support@bydash.com.

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. STOREBOUND SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

REPAIRS

DANGER! Risk of electric shock! The Dash Portable USB Blender is an electrical appliance.

Do not attempt to repair the appliance yourself under any circumstances.

Contact Customer Support regarding repairs to the appliance.

TECHNICAL SPECIFICATIONS

Power Rating 7.4V (9.62WH)

Stock#: DPPB120_20220517_v1

Made in China





1-800-898-6970 | @bydash | bydash.com