

INSTRUCTION BOOKLET

How to Use Stopwatch Mode

Select a timer using the Timer Buttons. Ensure timer is at zero. Press Start/Stop button. Timer will begin counting up until you press the Start/Stop Button again. There will be a + symbol next to a timer to indicate it's in Stopwatch Mode.

Adjusting the Volume

Hold down the 0 button until the screen changes. Select your volume level by pressing one of the Timer Buttons; T1 is the lowest setting, T3 is the loudest. Press the 0 button again to set your volume.

Power

Timer takes three AAA batteries (included) to operate.

The screen will go into standby mode after 60 seconds to preserve power, but any active timers will continue running. Press any button to wake the Timer up.

Cleaning & Care

Do not submerge Timer in water. To clean, wipe surface with a damp cloth.



GOOD GRIPS®

Triple Task Kitchen Timer Instructions For Use

OUTSIDE SPREAD



How to Set Countdown Timers

Use the Timer Buttons (T1, T2, T3) to select which timer you want to set. Once your desired timer is selected, use the Number Buttons to select the amount of time. Time is displayed in hours, minutes, and seconds (HH:MM:SS).

Press the Start/Stop Button to start timer. Press again at any time to pause or stop the timer. In this mode, timer will count down and will beep when it reaches zero. The timer will then start counting up and a plus sign will appear until Start/Stop button is pressed to stop the timer.

Note: Timer 1 will beep once when it reaches zero, Timer 2 will beep twice, and Timer 3 will beep three times.

Use the Timer Buttons to switch between timers and use the number buttons to set additional timers. This will not affect any timers already running.

Memory/Clear Button

Press the Memory/Clear button to reset the timer back to zero at any time.

If you press the Memory/Clear button while a timer is at zero, it will recall the last time that timer was set at.

INSIDE SPREAD