



# GOOD GRIPS®


VEGETABLE CHOPPER  
WITH EASY-POUR OPENING



**⚠ WARNING:** The OXO Good Grips Vegetable Chopper is very sharp. Handle with care when unpacking, using, cleaning and storing the Vegetable Chopper. Do not leave the Vegetable Chopper within reach of children. Not for use with meats and cheeses.

## PREPARATION

1. Cut food as illustrated below before placing on Chopper.




## TO USE


1. Open Chopper and place food on cutting area, cut side down.
2. Close lid, place hands on soft touch point and push down quickly and firmly to chop food.

## TO CLEAN

1. Remove grid to clean excess food between teeth.
2. Open lid and lift to separate from body.



3. Remove top of container by pressing on the 3 dots located under the opening at the back of the container.



All pieces are top-rack dishwasher safe.