

use & care

- Wash before first use.
- Do not use on stovetop or in broiler.
- Avoid sudden temperature changes by not placing hot Anyday dish on wet or cold surfaces or cold liquid in hot Anyday dish.
- Do not microwave empty Anyday dish.
- Lift knob to allow steam to escape while cooking.
- Do not use if Anyday dish is cracked.
- Use knob to lift only the lid (not entire Anyday dish).
- Leave 1 inch (2.5 cm) space at top of Anyday dish to prevent spills.
- Preheat oven before inserting Anyday dish.
- Avoid abrasive cleaning pads and steel wool.
- Use oven mitts to remove hot Anyday dishes from microwave.
- Due to glass material, slight variations like unique patterns, imperfections, or inconsistencies may occur.

We want you to love and use your Anyday dishes everyday.
If that's not the case, we'll make it right.
Visit [cookanyday.com](https://www.cookanyday.com) for your local warranty policy.