# WILLIAMS-SONOMA

## Devon Chandelier Assembly Instructions

### Important Safety Instructions:

- These instructions are provided for your safety. It is important that they are read carefully and completely before installing fixture.
- We strongly recommend that a professional electrician install all direct-wired fixtures.
- This fixture has been rated for up to (6) 40-watt max. Type B candelabra bulbs (not included). To avoid the risk of fire, do not exceed the recommended wattage.

WARNING: This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light fixture.

#### Pre-assembly:

- For your safety and convenience, assembly by two people is recommended.
- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

#### Parts Enclosed:

- (1) Crossbar
- (1) Ceiling loop
- (1) Canopy
- (1) Lock collar
- (1) Chain
- (1) Top loop
- (1) Top cap with upper hanging rings
- (6) Extension Rods
- (1) Fixture body with lower hanging rings
- (6) Lamp Shades

#### Hardware included:

- (2) Mounting screws
- (1) Green ground screw
- (3) Wire nuts


#### To Install You Will Need:

- Screwdriver
- Pliers
- Electrical tape

#### To Install:

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
- 2. Attach chain top loop on top cap by opening and re-closing one link with pliers. Note: use a soft cloth between the pliers and chain to prevent damage to chain finish.
- 3. Feed lantern wire through alternating links in chain and through lock collar and ceiling loop.
- 4. Slide canopy onto chain.
- 5. Determine the desired hanging length of lantern. Adjust chain length by using pliers to open and re-close links. Note: use a soft cloth between the pliers and chain to prevent damage to chain finish.
- 6. Fasten chain to ceiling loop.
- 7. Attach the extension rods to the top cap and fixture body as shown in the diagram.
- 8. Gently pull wiring from ceiling outlet box and allow the wires to hang.
- 9. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED. If your outlet box DOES NOT have a GROUND WIRE, be sure to insert the green ground screw into the crossbar facing DOWN, and wrap the fixture's bare copper ground wire around the ground screw on the crossbar. If your outlet box has a GROUND WIRE (green or bare wire) attach this wire to the bare copper GROUND WIRE of the fixture. Fasten with a plastic wire nut and wrap with electrical tape.
- 10. Carefully inspect the lantern's two fixture wires. One has very fine ridges molded into the plastic covering this is the NEUTRAL WIRE. The second wire's covering is smooth this is the HOT WIRE.
- 11. Connect the NEUTRAL WIRE from the fixture to the NEUTRAL JUNCTION BOX WIRE from the outlet box (usually white). Fasten each together with a plastic wire nut and wrap the connection with electrical tape. Be sure that no wire strands are exposed.
- 12. Connect the HOT WIRE from the fixture to the HOT JUNCTION BOX WIRE from the outlet box (usually black). Fasten each together with a plastic wire nut and wrap the connection with electrical tape. Be sure that no wire strands are exposed.
- 13. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED!
- 14. Tuck the wire connections neatly into the ceiling outlet box.
- 15. Attach the crossbar to the ceiling outlet box with the mounting screws. Tighten with screwdriver.
- 16. Attach the ceiling loop to the crossbar as shown.

- 17. Slide canopy over the chain and ceiling loop until it is flush with the ceiling.
- 18. Tighten the canopy by screwing the lock collar to the base of the canopy until snug.
- 19. Insert bulbs (not included) into sockets.
- 20. Restore power to outlet box and test fixture.
- 21. Assembly is complete



thank you for your purchase
Williams Sonoma, Inc. | Customer Service 1.877.812.6235 | www.williams-sonoma.com