

TOB5005

ASSEMBLY & INSTALLATION GUIDE

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Remove mounting plate (A) & back plate (B) from fixture base (D) by removing base screws (E) in counterclockwise direction.
2. Thread extension rods (H) into top threaded opening of part (J).
3. Attach fixture base (D) to extension rods (H), letting top nipple of extension rod (H) pass through the hole on fixture base (D), and secure with washer (G) & nut (F).
4. Attach the ground (bare copper) wire to the ground wire from the ceiling outlet box (usually green or copper in color), and fasten together with a plastic wire connector. Tightly wrap the wire connector with electrical tape so the end of the connector is sealed. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
5. Connect the neutral (RIBBED, without any marking) fixture wire coming from the fixture base to the neutral (usually white) outlet wire. Fasten both wires together with a plastic wire connector and tightly wrap the wire connector with electrical tape.
6. Repeat the procedure with the hot (ROUND, with UL marking on) wires. Always make sure that no wire strands are left outside the connectors. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
7. Affix mounting plate (A) & back plate (B) to ceiling outlet box with the back plate screws (C) & (K).
8. Attach fixture base (D) to the affixed back plate (B) and tighten with base screws (E).
9. Insert light bulbs into sockets.

